


Technical Manual

IT8000ET



Industrial Weighing Terminal With Touch Screen

December 2013

ST.2309.1472

Rev. 2

Technical Manual IT8000ET

Date: December 10, 2013

File: IT8000ET_THE.DOC

Program Version: as of firmware 'Update_20131105.1.IT468E'

Published By:

© SysTec Systemtechnik und Industrieautomation GmbH, Bergheim, Germany

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording, or otherwise, without the prior written permission of SysTec GmbH.

Terms and product names mentioned in this publication are trademarks, registered trademarks or service marks of their respective owners. Use of a term should not be regarded as affecting the validity of any trademark, registered trademark or service mark.

TOLEDO® and DigiTOL® are registered trademarks of Mettler-Toledo Inc.

Please Note:

While every precaution has been taken in the preparation of this manual, SysTec GmbH assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

The publisher is grateful for any information and/or advice that may contribute to correct errors or omissions in following editions.

Contents

1 Introduction	7
1.1 Safety Symbols Used In This Manual	7
1.2 General Safety Advice	7
1.3 Declaration Of Conformity IT8000ET	9
1.4 Declaration Of Conformity 'ITX000ET External Power Supply	10
2 System Description	11
3 Installation	12
3.1 Safety Advice	12
3.2 Setup Of The Instrument	12
3.3 Connection Of Cables.....	12
3.4 Connection Overview	13
3.5 Connection Of Scales	14
3.6 Connection Of Serial Interfaces (SIM And DUAL-ISM)	21
3.7 Connection Of Single-/Dual-Channel Pulse Wheel (DUAL-ISM)	26
3.8 USB Connection	26
3.9 Ethernet Connection.....	27
3.10 Connection Of WLAN Module WLX.....	28
3.11 Connection Of Digital I/Os (PIM)	29
3.12 Connection Of 15-Bit Analog Output (DAU15).....	32
3.13 Connection Of 15-Bit Analog Input ADI	34
3.14 Connection Of Profibus Module PBU	35
3.15 Connection Of PROFINET Module PNU	37
3.16 Connection To Power Supply 12 – 30 VDC	40
3.17 Enable On/Off Switch.....	40
3.18 ITX000ET External Power Supply 110 – 240 VAC (T8PWS001)	41
4 Weight Display And Scale Function Keys	42
4.1 General Operation	44
4.2 Operation Of Scale Functions	45
5 Service Mode	46
5.1 General.....	46
5.2 Access To Service Mode	46
6 Configuration	48
6.1 Configure Scale	48
6.2 Configure Digital I/Os	50
6.3 Configure Analog Outputs.....	50
6.4 Configure Analog Inputs	52
6.5 Configure Fieldbus Module	53
7 Calibration Mode	54
8 Entry Of Parameters (General)	55
9 Interface Configuration	58
9.1 Configuration of Ethernet interface	58
9.2 Configuration of serial interfaces	59
10 Network	61
11 WLAN	62
11.1 Configuration	62

11.2 Service.....	63
11.3 Reset WLAN	64
11.4 LEDs On The WLX Module	64
12 Test (Hardware)	65
12.1 Test Of Digital Inputs/Outputs.....	65
12.2 Test Of Serial Interfaces	66
13 Reset	67
13.1 Reset Parameters	67
13.2 Reset Approved Weight.....	67
14 Data Archive	68
15 Continuous Output	69
15.1 SysTec Standard Protocol.....	69
15.2 Flintec Protocol	69
15.3 SysTec Remote Protocol	69
15.4 Schauf Protocol.....	69
16 Transport, Maintenance And Cleaning.....	71
16.1 Transport	71
16.2 Maintenance	71
16.3 Cleaning.....	71
16.4 Replacing The Battery	72
17 Trouble Shooting	73
17.1 Error Log Of Scale	74
17.2 Error Messages	75
18 Technical Data	77
18.1 IT8000ET	77
18.2 ITX000ET External Power Supply Unit	78
19 Dimensions	79
19.1 IT8000ET	79
19.2 ITX000ET External Power Supply Unit	80
20 Service Password	81

1 Introduction

IT8000ET is a universal industrial weighing terminal for weighing and data capture applications. A touch sensitive 7" TFT color display is used for operation and indication of weight and additional information. This manual contains information and Technical Data for installation and operation of the IT8000ET weighing terminal and the optional power supply unit 'ITX000ET Externes Netzteil' (external power supply).

Further information is provided in the following manuals:

- ADM / DUAL-ADM / ADM8000-Exi Calibration Manual, order-No.: ST.2309.0688
- Flintec / HBM Calibration Manual, order-No.: ST.2309.1568
- MultiRange Calibration Manual, order-No.: ST.2309.0057

1.1 Safety Symbols Used In This Manual

Safety relevant information is shown with corresponding symbols as follows:



W A R N I N G

Failure to observe this precaution could result in serious injuries or fatal accidents. Please make absolutely sure that these precautions are observed in order to ensure safe operation of the equipment.



CAUTION

- Failure to observe this precaution could result in damage to or destruction of the equipment or bodily harm! Please make absolutely sure that these precautions are observed in order to ensure safe operation of the equipment.

Note: This indicates an advice for the designated use of the equipment and/or additional information to avoid inappropriate handling.

1.2 General Safety Advice



W A R N I N G

Exercise utmost care when making checks, tests and adjustments that can actuate movable parts such as feeding devices, gates, flaps, conveyors, etc. Make absolutely sure that nobody is within reach of movable parts.

Failure to observe this precaution could result in bodily injury!



W A R N I N G

This unit must not be operated in a potentially explosive atmosphere!

It is the sole responsibility of the user to classify the area of installation and make sure that absolutely no potentially explosive atmosphere can be present at any time!



CAUTION

- When this unit is included as a component part of a system, the resulting system design must be reviewed by qualified personnel who are familiar with the construction and operation of all individual components in the system and the potential hazards involved. Failure to observe this precaution could result in bodily injury!



CAUTION

- This unit must be installed, serviced, and operated in strict compliance with all locally applicable safety regulations and the rules for the prevention of accidents!

**CAUTION**

- The power supply unit provides SELV voltages in accordance with EN 60950. Make sure that any peripheral device connected to the weighing terminal containing its own power supply also uses SELV voltages!

**CAUTION**

- This module and its associated equipment must be installed, adjusted and maintained by qualified personnel only!

**WARNING**

For the storage of volatile data the terminal contains a lithium battery. Risk of explosion if battery is replaced improperly! Replace only with battery of the same type or with compatible type recommended by manufacturer. Disposal of used batteries only as indicated by manufacturer.

If the external power supply unit 'ITX000ET Externes Netzteil' (external power supply) is used, also the following instructions must be observed:

**WARNING**

Before opening the housing pull the power plug or disconnect the unit from the mains supply. Risk of electrical shock!

**CAUTION**

- Input voltage of the unit must comply with local mains supply!

**CAUTION**

- If the line cord with connector is used as the means to separate the power supply from the mains, the wall outlet must be installed close to the unit and must be easily accessible! If a permanently connected mains cable is used, an easily accessible separator must be included in the supply circuit!

**WARNING**

- The device uses the short-circuit / overcurrent protection of the on-site mains supply.

Note:

- Only permit qualified personnel to operate this instrument!
Disconnect all power to this instrument before cleaning and servicing!
- All switch gear connected to the unit and/or installed close to it, such as relays and contactors, must be fitted with appropriate components (RC-modules, diodes) to suppress interference.
- In order to avoid static discharge, all metallic parts of a system must be thoroughly grounded. Movable parts, such as portable scales on plastic wheels, must be grounded with earth clamps or earth leads of appropriate diameter.
- Keep this manual for future reference!

1.3 Declaration Of Conformity IT8000ET

SysTec Systemtechnik und Industrieautomation GmbH
Ludwig-Erhard-Str. 6
D-50129 Bergheim-Glessen



Konformitätserklärung

Declaration of conformity

Déclaration de conformité

Die nichtselbsttätige Waage

The non-automatic weighing instrument

L'instrument de pesage à fonctionnement non automatique



Hersteller:

Manufacturer:

Fabricant:

SysTec GmbH

Typ/Modell:

Type/Model:

Type/modèle:

IT8000ET

Nr. der EG-Bauartzulassung:

No of the EC type-approval certificate:

N° du certificat d'approbation CE de type:

D11-09-012

entspricht dem in der Bescheinigung über die Bauartzulassung beschriebenen Baumuster sowie den Anforderungen der folgenden Richtlinien:

Corresponds to the production model described in the EC type-approval certificate and to the requirements of the following EC directives:

Correspond au modèle décrit dans le certificat d'approbation CE de type, aux exigences des directives CE suivantes:

2009/23/EG	2009/23/EC	2009/23/CE
2004/108/EG	2004/108/EC	2004/108/CE
2006/95/EG	2006/95/EC	2006/95/CE

entsprechend den folgenden Normen/Empfehlungen:

in conformity with the following standards:

conforme aux normes suivantes:

EN 45501	OIML R76-1	
EN 61000-6-2	EN 61000-6-3	NAMUR NE21
EN 60950		

Nur gültig mit einer von einer Benannten Stelle erteilten Konformitätsbescheinigung.

Only valid with a Certificate of Conformity issued by a Notified Body.

Seulement valable avec une Attestation de Conformité délivré par une organisme notifié.

Unterschrift

Signature

Signature

Datum:

10.05.2012

Date:

May 10, 2012

Date:

10.05.2012

Dipl.-Ing. Rainer Junglas

Geschäftsführer / General Manager / Directeur

1.4 Declaration Of Conformity 'ITX000ET External Power Supply

SysTec Systemtechnik und Industrieautomation GmbH
Ludwig-Erhard-Str. 6
D-50129 Bergheim-Glessen

Systemtec



Konformitätserklärung
Declaration of conformity
Déclaration de conformité

Die nichtselbsttätige Waage

The non-automatic weighing instrument

L'instrument de pesage à fonctionnement non automatique



Hersteller:

Manufacturer:

Fabricant:

SysTec GmbH

Typ/Modell:

Type/Model:

Type/modèle:

ITx000ET Externes Netzteil
External Power Supply
Bloc d'alimentation externe

entspricht dem in der Bescheinigung über die Bauartzulassung beschriebenen Baumuster sowie den Anforderungen der folgenden Richtlinien:

Corresponds to the production model described in the EC type-approval certificate and to the requirements of the following EC directives:

Correspond au modèle décrit dans le certificat d'approbation CE de type, aux exigences des directives CE suivantes:

2004/108/EG	2004/108/EC	2004/108/CE
2006/95/EG	2006/95/EC	2006/95/CE

entsprechend den folgenden Normen/Empfehlungen:

in conformity with the following standards:

conforme aux normes suivantes:

EN 61000-6-2	EN 61000-6-3
EN 60950	

Nur gültig mit einer von einer Benannten Stelle erteilten Konformitätsbescheinigung.

Only valid with a Certificate of Conformity issued by a Notified Body.

Seulement valable avec une Attestation de Conformité délivré par une organisme notifié.

Unterschrift

Signature

Signature

Datum:

03.07.2013

Date:

July 03, 2013

Date:


03.07.2013

Dipl.-Ing. Rainer Junglas

Geschäftsführer / General Manager / Directeur

2 System Description

This weighing terminal features a modular design with plug-on modules.



For more detailed information on the individual plug-on modules, the TFT display and the power supply refer to chapter 'Installation'.

LEDs on mainboard

LED	Function	
V44	3V3	3.3V CPU logic
V42	5V	5V peripherals
V41	12V	12V peripherals
Ethernet interface:		
V2	LAN	Traffic / connected
ADM scale modules:		
V43	ANA:5V	5V for ADM

PIM logic side active:		
V10	IN0	PIM1 input #1
V11	IN1	PIM1 input #2
V6	OUT0	PIM1 output #1
V7	OUT1	PIM1 output #2
V12	IN2	PIM2 input #1
V13	IN3	PIM2 input #2
V8	OUT2	PIM2 output #1
V9	OUT3	PIM2 output #2

3 Installation

3.1 Safety Advice



WARNING

Before opening the housing disconnect all power to the instrument. Only connect / disconnect any cables when unit is completely deenergized. Failure to observe this precaution could result in bodily injury!

Notes:

- Transport and storage of electronic components such as boards, EPROMs, etc. must only be made in suitable anti-static ESD bags or cases.
- Shielding measures for the connection of cables must absolutely be adhered to. Insufficient shielding may cause interference and could result in malfunction of the instrument.


3.2 Setup Of The Instrument

Ambient temperature for operating the unit may range from -10°C to $+40^{\circ}\text{C}$, at a maximum of 95% relative humidity, without condensation. Exposure to direct sunshine should be avoided.

For wall-mount applications the terminal can be fixed at the wall first, the connection cables can be fitted later with the lid of the housing removed.

3.3 Connection Of Cables

All cables are led into the housing through cable glands.



Cable connection through cable glands:


1. Slide compression nut over cable jacket;
2. Slide plastic insert (retainer) over cable jacket until inner end is aligned with cut end of jacket;
3. Unravel shield, bend over retainer and push into retaining comb. Cut wires of shield to length of comb, avoid protruding wires;
4. Insert retainer with cable into bushing;
5. Screw compression nut onto bushing and use wrench to tighten securely.

3.4 Connection Overview

3.4.1 ADM


6-wire	
1	+ Excitation
2	– Excitation
3	+ Sense
4	– Sense
5	+ Signal
6	– Signal

4-wire	
1 / 3	+ Excitation
2 / 4	– Excitation
5	+ Signal
6	– Signal




3.4.2 CPU

KL2 Serial interface 1 (COM1) KL3 Serial interface 2 (COM2)			
Terminal#	RS232	20mA	RS485 4-wire
1	TxD	TX _{IN}	Tx A (Tx +)
2	RTS	TX _{OUT}	Tx B (Tx –)
3	RxD	RX _{IN}	Rx A (Rx +)
4	CTS	RX _{OUT}	Rx B (Rx –)
5	Gnd	—	—



KL4 / 5: digital inputs and outputs 0 - 3			
KL4	KL5		
1		0V	
2		+ 12V	for external switches only!
3		IN0	
4		IN1	
5		IN2	
6		IN3	
	1	IN–	for IN0 - IN3
	2	OUT0	
	3	OUT1	
	4	OUT2	
	5	OUT3	
	6	OUT+	for OUT0 - OUT3



Terminal assignment of DAU15			
DAU15 in socket:		PIM1	PIM2
I+	+ Current output 0/4 - 20mA	KL4.3	KL4.5
I–	– Current output 0/4 - 20mA	KL4.4	KL4.6
U+	+ Voltage output 0/2 - 10V	KL5.2	KL5.4
U–	– Voltage output 0/2 - 10V	KL5.3	KL5.5

Klemmenbelegung bei Einsatz der ADI			
ADI in socket:		PIM1	PIM2
I+	+ Current input 0/4-20mA	KL5.2	KL5.4
I–	– Current input 0/4-20mA	KL5.3	KL5.5
U+	+ Voltage input 0/2-10V	KL4.3	KL4.5
U–	– Voltage input 0/2-10V	KL4.4	KL4.6



3.5 Connection Of Scales

3.5.1 Connection Of Analog Scale To ADM

The ADM module provides connection for weighing platforms and loadcells as specified below. One or two scale interface modules can be installed.


- Max. 8 strain gauge loadcells 350 Ω each
- Overall impedance 43 Ω ... 4500 Ω
- W&M approved resolution of 6000d at a max. preload of 80%, internal resolution 524,000d
- Smallest permissible input signal for approved applications: 0.33 μV / e
- Update rate 50-400 updates / second (selectable in Service Mode)
- Loadcell excitation: 5 V $\pm$ 5% (gated power supply).

Principal schematics of 6-wire and 4-wire strain gauge loadcell:



Connection of 6-wire analog loadcell(s) to ADM:


Terminal Assignment	
1	+ Excitation
2	- Excitation
3	+ Sense
4	- Sense
5	+ Signal
6	- Signal



Connection of 4-wire analog loadcell(s) to ADM:


To connect loadcells without sense lines (4-wire connection), two jump leads must be connected between terminal 1 and 3, and between terminal 2 and 4.

Terminal Assignment	
1 / 3	+ Excitation
2 / 4	- Excitation
5	+ Signal
6	- Signal




3.5.2 Sealing Of Calibration Parameters

By means of the jumper W1 the calibration parameters stored in EEPROM can be protected against unauthorized modifications:



If required for W&M approved and stamped systems, the position of the jumper W1 can be sealed with thread and lead seal:




3.5.3 Connection Of Digital Mettler-Toledo Scale Bases With IDNet Interface

The **IDN** module (IDNet interface module) permits the connection of Mettler-Toledo scale bases with IDNet interface.

One or two IDN modules may be installed. If only one IDN is used, the remaining socket ADM2 can then be used for an additional ADM board to connect a scale base with up to 8 analog loadcells (350 Ω each). If an IDN module is installed in socket ADM2, the serial interface SIM2 must not be used!

The IDN module supplies a current of 150mA max. at 12VDV for the supply of the IDNet scale base.

IDN interface module




Terminal KL1	Signal	Function
1	TxD –	– transmit line 20 mA CL
2	TxD +	+ transmit line 20 mA CL
3	RxD –	– receive line 20 mA CL
4	RxD +	+ receive line 20 mA CL
5	0 V	0 V supply voltage
6	+ 12 V (150mA)	+ 12V supply voltage

IDNet understructures which operate on 12VDC power supply (e.g. TBrick) are connected with the IDNet scale cable 16KAB002.

For IDNet scale bases with 12V and 32V power supply (e.g. K-Cell) the external power supply unit IDNet-PSBox (10OPT124) is required. The connection is made with the IDNet scale cable 16KAB004.

Standard cable for the connection of digital weighing platforms (approx. 0.3m):

IDNet connecting cable for Mettler-Toledo scale bases
Art.-No. 16KAB002 / 16KAB004 (ST.2300.0064)



Terminal Strip KL1	Signal	Color	Pin Assignment (12-pin Binder Connector)
1	TxD-	yellow	J
2	TxD +	green	A
3	RxD-	white	F
4	RxD +	brown	D
5	0 V	pink	H
6	+ 12 V	gray	C
	+ 32V	blue	B

Note:

The blue wire of cable 16KAB002 (for IDNet scale bases with 12V supply) is not used and must be cut directly at the cable gland.

The pink and blue wires of cable 16KAB004 (for IDNet scale bases with 12V and 32V supply) are fitted with crimp contacts for connection to the IDNet-PSBox.

3.5.4 Interface For Digital Force Transducers with RS485 Interface (DWB)

The **DWB module** (Digital Weighing Board) permits the connection of one digital force transducer operating on 12VDC power supply and communicating with the weighing terminal via RS485 2-wire or 4-wire network.


At present, scale bases and loadcells are supported as follows:

- Sartorius series IS weighing platforms
- HBM series C16i loadcells
- Flintec series RC3D loadcells

Calibration data are stored powerfail-safe in a serial EEPROM on the DWB module. By means of the jumper W1 these data can be protected against unauthorized access.

One or two DWB modules may be installed. If only one DWB is used, the remaining socket ADM2 can then be used for an additional ADM board to connect a scale base with up to 8 analog loadcells (350 Ω each).


DWB interface module



Terminal KL1	Signal RS485 4-wire	Signal RS485 2-wire	Assignment
1	Tx A (Tx +)	A (Tx + / Rx +)	+ transmit line RS485
2	Tx B (Tx -)	B (Tx - / Rx -)	- transmit line RS485
3	Rx A (Rx +)	—	+ receive line RS485
4	Rx B (Rx -)	—	- receive line RS485

Standard cable for the connection of digital Sartorius weighing platforms series IS (approx. 0.3m):

RS485 2-wire connecting cable for Sartorius weighing platforms
Art.-No. 16KAB001 / ST.2300.0098




Terminal KL1 (DWB)	Signal	Color	Pin assignment (12-pin Amphenol connector)
1	Tx + / Rx +	green	L
2	Tx - / Rx -	yellow	A
—	Prog	blue *)	F

Terminal KL6 (CPU)	Signal	Color	Pin assignment (12-pin Amphenol connector)
0V	Gnd	brown / white	K + J + E
12V	+ 12V	gray / pink	G + M


*) Note: The blue wire (PROG) is not used and should be cut directly at the cable gland.

3.5.5 Sealing Of Calibration Parameters

means of the jumper W1 the calibration parameters stored in EEPROM can be protected against unauthorized modifications:



If required for W&M approved and stamped systems, the position of the jumper W1 can be sealed with thread and lead seal:




3.5.6 Connection Cables For Digital Force Transducers

Unsuitable cable may cause loss of data. For the installation of connection cables for **digital** weighing platforms please follow the recommendations listed below:

- Only use suitable connecting cable (data cable), e.g. 6 x 0.25 mm² shielded, SysTec order-No. 10KAB216, or data cable supplied by the manufacturers of scale base.
- Nominal Voltage of cable $\geq 250V$.
- Connect shield of cable at **both sides**, at cable gland of terminal and at scale base and/or extension cable. Install appropriate equipotential bonding if difference of potential is experienced.
- Distance between data cables and power lines: $\geq 0.5m$. Data cables to be installed in grounded metal conduits, metal hoses or metal cable trays.
- Maximum length of connection cable between weighing platform and terminal: 15m.

3.5.7 **Auxiliary Power Supply For Digital Force Transducers**

An auxiliary power supply of 12VDC for digital force transducers is available at terminals KL6 and KL7.



Assignment terminal strips KL6 and KL7

12V	12VDC (500mA in total) incl. current drawn at KL1
0V	0V (12)


3.6 Connection Of Serial Interfaces (SIM And DUAL-ISM)

The following plug-on modules for serial interfaces and an incremental sensor can be installed in the SIM sockets:

- 'SIM RS232' RS232 interface
- 'SIM 20mA' 20mA current loop interface
- 'SIM RS485.4' RS485/422 4-wire interface
- 'SIM RS485.OPTO' RS485 4-wire optoisolated interface
- 'DUAL-ISM' to connect dual-channel pulse wheel
- SPU only: 'SIM RS485.2' RS485 2-wire interface

Please note: When a 20 mA CL interface is used, receiver and transmitter of the weighing terminal are always passive, i.e. supply voltage for the current loops must be provided by the connected peripheral device.

Connection of serial interface on the mainboard:




Terminal assignment:

Serial interface 1 (COM1): KL1			
Serial interface 2 (COM2): KL2			
Terminal#	RS232	20mA	RS485 4-wire
1	TxD	TX _{IN}	Tx A (Tx +)
2	RTS	TX _{OUT}	Tx B (Tx -)
3	RxD	RX _{IN}	Rx A (Rx +)
4	CTS	RX _{OUT}	Rx B (Rx -)
5	Gnd	—	—

With SPU interface expansion module additional serial interfaces can be connected. The sockets SIM3 - SIM4 provide connection for up to 2 SIM modules.


Connections on SBU board



Connector SPU	Socket mainboard
X1	X26

Serial interfaces					
SIM3 (COM3)	SIM4 (COM4)	RS232	20mA	RS485 4-wire	RS485 2-wire
KL1.1	KL2.1	TxD	TX _{IN}	Tx A (Tx+)	A (Tx+ / Rx+)
KL1.2	KL2.2	RTS	TX _{OUT}	Tx B (Tx-)	B (Tx- / Rx-)
KL1.3	KL2.3	RxD	RX _{IN}	Rx A (Rx+)	—
KL1.4	KL2.4	CTS	RX _{OUT}	Rx B (Rx-)	—
KL1.5	KL2.5	Gnd	—	—	—

Principal circuit diagram of the 20mA current loop interface:



For the installation of connection cables for serial interfaces please follow the recommendations listed below:

- Install data cables to prevent capacitive or inductive interference from other cables, machines and/or electrical devices that could interrupt data transmission and lead to loss of data.
- For maximum suppression of interference, shield should be grounded on both sides.
- If fluctuation of the earth potential is experienced, this can cause an equalization current flowing over the shield. In this case a separate earth lead of appropriate diameter for potential equalization is required.
- Non-factory made cables must comply with the following specification:

Triple twisted pair plus shield, e.g. LIYCY 3 x 2 x 0.14mm² or LIYCY 3 x 2 x 0.25mm², shield grounded on both sides.

Resistance	≤ 125 Ω/km
Gauge	≥0.14 mm ² up to 200m, ≥0.25 mm ² up to 1200m
Capacitance	≤ 130 nF/km
Length RS232	max. 15m
Length RS485	max. 1200m
Impedance RS485	approx. 150 Ω
Nominal voltage	≥ 250V

For RS485 connections please note:


Terminal assignment: Some manufacturers of components with RS485 interface do not refer to the terminals TX+ and RX+ as 'A', but 'B' instead (correspondingly, the terminals TX- and RX- are not referred to as 'B', but 'A').

Cables: Use only twisted pair cables with a characteristic impedance of approx. 150 Ω.

Termination resistors: In order to prevent reflection (baud rate 19200 Baud or higher, and/or cable longer than 20 m) it is recommended to install termination resistors $R_{Term} = 150\ \Omega$ on both ends of the cable.


Pull-up / pull-down resistors: When termination resistors are used, also pull-up and pull-down resistors must be installed at the master (see also following schematic).

RS 485 network with termination, pull-up and pull-down resistors:




3.6.1 Standard Cables For Serial Interface

RS232 Printer Cable with male 25-pin DSUB-connector
Art-No. 10KAB200 / ST.2300.0021




Terminal				Printer
TxD	1	green	3	RxD
RTS	2	yellow	5	CTS
RxD	3	brown	2	TxD
CTS	4	white	20	DTR
Gnd	5	gray	7	Gnd

20mA Printer Cable with male 25-pin DSUB-connector
Art-No. 10KAB201 / ST.2300.0020



Terminal				Printer
TX _{IN}	1	green	23	RX _{OUT}
TX _{OUT}	2	yellow	25	RX _{IN}
RX _{IN}	3	brown	24	TX _{OUT}
RX _{OUT}	4	white	17	TX _{IN}

RS232 Data Cable with female 9-pin DSUB-connector
Art-No. 10KAB202 / ST.2300.0019



Terminal				PC
TxD	1	green	2	RxD
RTS	2	yellow	8	CTS
RxD	3	brown	3	TxD
CTS	4	white	7	RTS
Gnd	5	gray	5	Gnd
			1	
			4	
			6	

approx. 3m

3.7 Connection Of Single-/Dual-Channel Pulse Wheel (DUAL-ISM)

A pulse wheel (rotary pulse transmitter) can be connected to the indicator by means of a dual-channel (DUAL-ISM) interface (Impulse Sensor Module) plugged into one of the sockets SIM1 to SIM2 (SIM3/4 on SPU).

At the terminal strip KLx dual-channel incremental sensors (pulse wheels) can be connected that operate on 10VDC and have PNP or push-pull outputs.

When a single-channel sensor is connected, terminal KLx.4 remains free.

Terminal assignment of DUAL-ISM

KLx	Assignment	Designation	Comment
1	10V	Supply for pulse wheel	100mA max.
2	5V	–	
3	CHA	Pulse wheel channel A	Off = 0...3V On = 7...10V
4	CHB	Pulse wheel channel B	Off = 0...3V On = 7...10V
5	GND	GND supply for pulse wheel	


3.8 USB Connection

The SysTec 'USB memory stick, internal', No. 19OPT601 plugs directly into X5 on the mainboard. The USB connection can be led to the outside of the housing with one of the following options:

- 18OPT500, USB kit, USB socket protected to IP67, the counter nut must be firmly tightened;
- 10KAB431, patch cable 0.15m with cable gland and USB socket type A;
- 10KAB432, patch cable 3m with cable gland and USB socket type B.

Note:

- Internally the cable plugs into connector X4 on the mainboard. When inserting the connector, observe the color coding as shown bellow:



- When the external USB connection is used, the internal one (X5 on the mainboard) must not be used.

When a USB keyboard is used, the following assignment applies:

USB keyboard	Terminal	USB keyboard	Terminal
F1-F6	F1-F6	F10	
Tab		F11	
F8		F12	
F9			

3.9 Ethernet Connection

Connection to a local 10/100MBit Ethernet network is made via a connecting cable with RJ45 connector (internal connection at X2 on main board):

- 10KAB405, Ethernet cable 5m with cable gland and RJ45 connector;
- 10KAB410, Ethernet cable 10m with cable gland and RJ45 connector;
- 10KAB420 + 10KAB421, Ethernet cable with cable gland and RJ45 connector, customized cable length.

Note:

- When the external Ethernet connection is used, the WLAN module WLX cannot be connected at X3.
- Max. permissible cable length without repeater (hub/switch) is 80m

When assembling your own cables, the shield of the cable must be connected inside the cable gland as shown below:




- Strip approx. 10mm of cable jacket where cable gland is to be installed;
- Run cable through cable gland until shield of cable has reached the contact position;
- Tighten cable gland.

3.10 Connection Of WLAN Module WLX

For the WLAN connection (wireless network) the WLX module is plugged onto the main board and the antenna is connected.

Connections on WLX module



WLX	Socket mainboard
X1	X3
X2	Reset

Note: Use of WLX module (WLAN) and Ethernet connection (LAN) is NOT possible at the same time.


3.11 Connection Of Digital I/Os (PIM)

The digital input/outputs on the mainboard can be activated by inserting plug-on modules. Each module provides drivers for two optoisolated inputs and two optoisolated outputs.

Rating of outputs: 12-24VDC; 100mA max.

Current consumption of inputs: 7mA max. @ 12-24VDC.

Position and assignment of digital inputs/outputs on mainboard:



Terminal assignment			
KL4 / 5: digital inputs and outputs 0 - 3			
KL4	KL5		
1		0V	
2		+ 12V	for external switches only!
3		IN0	
4		IN1	
5		IN2	
6		IN3	
	1	IN-	for IN0 - IN3
	2	OUT0	
	3	OUT1	
	4	OUT2	
	5	OUT3	
	6	OUT +	for OUT0 - OUT3

Note: The internal 12 VDC supply (terminal row KL4, terminal #2) may be used to connect switches (max. 100mA) and push buttons to the digital inputs. External devices connected to the digital *outputs* must always be supplied from an external 24 VDC power supply.

With SPU interface expansion module additional digital interfaces can be connected. The sockets PIM3 - PIM4 provide connection for up to 2 SIM modules.

Digital I/Os on SPU:			
PIM3 KL3	PIM4 KL4		
1		0V	
2		+ 12V	only for external switches! (See note below).
3		IN4	
4		IN5	
5		IN6	
6		IN7	
	1	IN–	for IN4 - IN7
	2	OUT4	
	3	OUT5	
	4	OUT6	
	5	OUT7	
	6	OUT +	for OUT4 - OUT7

For the installation of connection signal cables please note:

Install I/O cables to prevent capacitive or inductive interference from other cables, machines and/or electrical devices that could affect input/output signals and lead to malfunction and/or dangerous operational conditions.


Cables must comply with the following specification:

- shielded multicore cables, shield connected to ground on both sides
- flexible wires with wire end ferrules and plastic collar
- Resistance $\leq 125 \Omega/\text{km}$
- Gauge 0.2 mm^2 to 0.5 mm^2 max.
- Capacitance $\leq 130 \text{ nF/km}$
- Length max. 15 m
- Nominal voltage $\geq 250 \text{ V}$


Note:

- For maximum suppression of interference, shield should be grounded on both sides.
- If fluctuation of the earth potential is experienced, this can cause an equalization current flowing over the shield. In this case a separate earth lead of appropriate diameter for potential equalization is required.
- The digital outputs on the mainboard and/or the SPU interface board use one common connection OUT + , the digital inputs use the common connection IN–.

Principal schematics



Digital output




Digital input

3.12 Connection Of 15-Bit Analog Output (DAU15)

For the output of gross or net weight as analog 15-bit signal a plug-on module (DAU15) can be inserted in the socket PIM1 or PIM2 (PIM3/4 on SPU). The output signal has a resolution of 15 bit (32768 steps). The module can be configured in the Service Mode to 0/2 - 10V or 0/4 - 20mA. The output of the DAU15 module is active and potential free.


Installing the DAU15 in a PIM socket on the mainboard



Terminal assignment of DAU15:


DAU15 in socket:		Mainboard		SPU	
		PIM1	PIM2	PIM3	PIM4
I+	+ Current output 0/4 - 20mA	KL4.3	KL4.5	KL3.5	KL3.3
I-	- Current output 0/4 - 20mA	KL4.4	KL4.6	KL3.6	KL3.4
U+	+ Voltage output 0/2 - 10V	KL5.2	KL5.4	KL4.4	KL4.2
U-	- Voltage output 0/2 - 10V	KL5.3	KL5.5	KL4.5	KL4.3

Example for current output 0/4 - 20 mA (DAU15 in socket PIM1):



The impedance of the connected load must not exceed 500 Ω .

Example for voltage output 0/2 - 10 V (DAU15 in socket PIM2):




The impedance of the connected load must be equal or greater than 500 Ω .

3.13 Connection Of 15-Bit Analog Input ADI

For the measurement of analog voltages or currents the plug-on module ADI can be installed in socket PIM1 or PIM2 (PIM3/4 on SPU). The input signal has a resolution of 15 bit (32768 steps). The input of the ADI module is potential free.

Installing the ADI in a PIM socket on the mainboard



Terminal assignment of ADI:			
ADI in socket:		PIM1	PIM2
I+	+ Current input 0/4-20mA	KL5.2	KL5.4
I-	- Current input 0/4-20mA	KL5.3	KL5.5
U+	+ Voltage input 0/2-10V	KL4.3	KL4.5
U-	- Voltage input 0/2-10V	KL4.4	KL4.6


The impedance of the current input is 24 Ω .

The impedance of the voltage input is 105 k Ω .

3.14 Connection Of Profibus Module PBU

The PBU expansion board provides connection of the weighing terminal to the Profibus DP field bus.

Connections on PBU module



Connector PBU	Socket mainboard
X1	X26

Terminal assignment Profibus DP interface:

KL1	Profibus DP
1	RTS
2	Gnd 5V
3	+ 5V
4 / 6	B Line
5 / 7	A Line

LED Profibus interface V3:

On	Error / not configured (when terminal is switched on)
Flashing	No active Profibus connection
Off	Profibus connection active

Function of jumpers W1-W3

Jumper	Profibus DP interface
W1	Pull-up resistor
W2	Termination resistor
W3	Pull-down resistor

If the terminal is connected to a physical end of the Profibus DP bus, the jumpers W1, W2 and W3 must be set to terminate the bus, (the line is terminated when the jumpers are closed)


3.14.1 Configuration of Profibus DP

The Profibus address is set in Service Mode (see also Installation Instructions of application program).

With the PBU expansion module the weighing terminal operates as a Profibus DP slave, with an I/O interface (64 inputs and outputs) or a data interface with 64 input words and 64 output words. The PBU module is designed for transmission speeds of 12 MBit/s. The definition of the individual data words depends on the application and is specified in the Installation Instructions pertaining to the respective product.

For the configuration of the Profibus master, a GSD file is required that you can download from our website 'www.systecnet.com'.

- Follow the link 'Service' and from there to 'download software'.




- Download the file 'GSD.ZIP' (click right on the link and choose 'Save Target As...'). Unpack the ZIP file on your hard disk.

3.15 Connection Of PROFINET Module PNU

The extension module (PNU) enables the connection of the weighing terminal to PROFINET networks.

Connections on PNU module



Connector X1

Connector PNU	Socket mainboard
X1	X26

Socket X2, X3

Socket PNU	PROFINET
X2	RJ45 line 1
X3	RJ45 line 2

3.15.1 External Connection PROFINET

Connection to local 10/100MBit PROFINET networks is made with one of the following cables with RJ45 connector (plugged internally into X2 and/or X3 on the PNU board);

- 10KAB440, Ethernet cable 5m with EMC cable gland and RJ45 connector;
- 10KAB441, Ethernet cable 10m with EMC cable gland and RJ45 connector;
- 10KAB442 + 10KAB443 or 10KAB442 + 10KAB444, Profinet cable with one or two EMC cable Glands and RJ45 connector, customized length, to be specified.

Note:

- Cable length of one segment without repeater (switch) max. 80m;
- The required EMC cable gland is available under art.-No. 10KAB422.

When assembling your own cables, the shield of the cable must be connected inside the cable gland as shown below:



- Strip approx. 10mm of cable jacket where cable gland is to be installed;
- Run cable through cable gland until shield of cable has reached the contact position;
- Tighten cable gland.

3.15.2 PROFINET Configuration

The PROFINET module is activated in the Service Mode under 'Config\Fieldbus\PROFINET'.

The IP address of the PROFINET module is set in the PLC and not in the weighing terminal.


With the PNU extension module the weighing terminal works as PROFINET I/O unit, providing an I/O interface with 64 input words and 64 output words. The PNU module supports transmission speeds of up to 100 MBit/s. The contents of the individual data words is defined in the application program and described in the pertaining operation manual.

To configure the PROFINET I/O controller, a GSDML file is required that you can download from our website 'www.systecnet.com'.

- Follow the link 'Service' and then 'Download Software'.

download software		
File	Filesize	Description
EtherPort Tool 3.3.zip	(4MB)	SysTec Ethernet IP c
GSD.zip	(39kb)	GSD Files Profibus C
GSDML-V2.2-SysTec GmbH 0241-ITx000-20121124.zip	(5kb)	PROFINET GSDML
IT4000	(152kb)	IT4000E Applikations
PC Remote	(753kb)	PC Remote Display
Update	(1.9MB)	Firmware for IT4000E

- Download the file 'GSDML-Vx.y-SysTec GmbH 0241-ITx000-yyyyymmdd.ZIP' (click right on the link and choose 'Save target as'). Unzip file on your harddisk.



Module status LED:

V5 (green)

State	Indication
Off	Not configured (when terminal is on)
Flashing	No active PROFINET connection
On	PROFINET active

PROFINET status LEDs:

V1 maintenance (yellow)

State	Indication
Off	Maintenance not required
On	Maintenance required

V2 system fail (red)

State	Indication
Off	PROFINET diagnosis available
On	No PROFINET diagnosis available

V3 Bus Failure (rot)

State	Indication
Off	PROFINET connection to I/O IO controller active
Flashing	PROFINET connection active, no communication with another PROFINET I/O controller
On	No active PROFINET connection

V4 device ready (green)

State	Indication
Off	PNU module not correctly initialized
Flashing	Waiting on connection to CPU8000E module
On	PNU module correctly initialized


3.16 Connection To Power Supply 12 – 30 VDC

IT8000ET is intended for connection to a supply voltage of 12 VDC (–15 %) to 30 VDC (+ 10 %).

The external voltage is connected at terminal X4 on the basic board PTA (Power-Supply-Touch-Adapter). This board contains a DC/DC converter (30W, 12 - 30 VDC input / 12 VDC output), the connection to the touch screen with LVDS converter and the monitoring of the battery charge state. The board has a fused input (2A T). A diode serves as protection against polarity reversal.

Terminal assignment X4

X4	Assignment
PA	Gnd (housing)
–	0 VDC
+	+ 12VDC to + 30 VDC



3.17 Enable On/Off Switch




The jumper X24 on the mainboard determines the function of the on/off switch, see also section 'System Description':

- Jumper inserted: On/off switch disabled, when connected to power supply the terminal starts immediately.
- Jumper removed: The terminal only starts after pressing the on/off switch.

3.18 ITX000ET External Power Supply 110 – 240 VAC (T8PWS001)

'ITX000ET Externes Netzteil' (external power supply) is suitable for the supply of the IT8000ET weighing terminal. For connection to the 110-240 VAC mains supply it has a line cord with safety plug. The output voltage of 12VDC is available at a 2-core cable of 1m length with free ends and can be connected at the input terminals X4 of the IT8000ET weighing terminal.



Technical data and assignment:

Input:	
Input voltage:	110-240 VAC / 47-63 Hz; 0,4-0,2 A
Connection:	Line cord of 2.5m length with safety plug
Output:	
Output voltage:	12 VDC; 2.0 A
Connection:	2-core cable of 1m length, color code: brown: + 12 VDC white: 0 VDC

Safety advice:


- Input voltage of the unit must comply with local mains supply: 110–240 VAC / 47-63 Hz.
- The mains supply of the unit should not be used at the same time for machines or equipment that can cause interference (e.g. motors, relays, heatings, etc.). Even short spikes or interruptions may affect the function of the unit or cause damage. An uninterruptable power supply (UPS) can prevent problems of this nature.
- Mains supply is made via a factory-installed line cord of 2.5m length with safety plug. Make sure that wall outlet is correctly grounded!
- The wall outlet must be installed close to the unit and must be easily accessible!
- The device uses the short-circuit / overcurrent protection of the on-site mains supply.



WARNING

Parts of the power supply unit -in particular the heat sinks- are directly connected to dangerously high voltages! A defective power supply unit cannot be repaired it can only be replaced. Disconnect all power to the unit before servicing!

4 Weight Display And Scale Function Keys



Please note that 'key' refers to the corresponding sensor field of the currently displayed template, in the same way 'pressing a key' is to be understood as touching the respective field of the touch panel.

Scale Function Keys



Set Zero Key to set the displayed scale to zero (only within zero setting range, selectable in calibration mode). ^{*1}



Key to switch auxiliary display between tare weight / gross weight / bargraph / weight storage / Firmware Information / Monitor options



Tare Key for alternately taring of currently displayed weight or clearing the tare weight. ^{*1}



Tare entry key to enter preset tare in the tare line, the value is applied after confirmation with the Enter-key. ^{*1}

^{*1} Function can be disabled in application program.


Electronic Marking Plate (only for single- and dual-range and two-interval scales)

Scale-No.	W1 ... W8	No. of scale selected via Scale Select Key.
Max Load	e.g.: Max 3000kg	Maximum load (without additive tare), selectable in calibration mode.
Min Load	e.g.: Min 20kg	Permissible minimum load.
Division e / d	e.g.: e=d= 1kg	Approved division e and display graduation d (in most cases e = d).

Weight Display


Scale-No. / No. Of Weighing Range	W1 ... W8 W1.1 ... W8.3	No. of scale selected via Scale Select Key partial weighing range for multiple-range scales.
No-Motion Symbol		Settled weight (printing / storing possible).
Gross Weight Or Net Weight	e.g. 1250 e.g. 650 Net	Switching from gross weight to net weight with Tare-key.
Net Weight Symbol	Net	Scale is tared.
Unit	e.g. kg	Weight unit, selectable in calibration mode.

Auxiliary Display (switchable via Display Select Key)

Tare	12,9kgT	Display of tare weight
Gross	1000kg	Display of gross weight
		Gross weight bargraph (zero to max load)
Approved weight storage		W&M approved data archive (see chapter 'Data Archive')
Firmware information		Show details of firmware version, Enter Mastermode
Monitor options		Adjusting the contrast of the display

Example for firmware information:

4.1 General Operation



-  Back to previous program step or previous line
-  Scrolling in records / columns of tables,
-  scrolling of lines right / left in edit functions
-  Switching to layout of alphanumeric keyboard
-  Switching to layout of numeric keyboard
-  Shift-key for capital letters
-  Delete characters
-  Enter-key

Confirmation of Entry / Choice of Function

Every entry or choice of parameter or function must be confirmed with the Enter-key, even if this is not explicitly stated in the following text. After pressing the Enter-key the program is continued in the next step.

4.2 Operation Of Scale Functions

Preset Tare (PT)



After pressing the PT-key, the template for numeric inputs is displayed and a tare value can be entered and confirmed with the Enter-key.

Indication of net weight in the main display and gross weight in the auxiliary display.



By pressing the Tare-key the tare is cleared and the main display returns to the indication of the gross weight.

Tare Balancing



By pressing the Tare-key, tare balancing is executed. By pressing the Tare-key once more the display returns to gross weight.

5 Service Mode

5.1 General

The Service Mode is a program for configuration, calibration and hardware test of the weighing terminal. Also, data can be backed up onto a PC.

Notes:


- This weighing terminal and its associated equipment must be installed, adjusted and maintained by qualified personnel only!
- Before accessing the Service Mode all peripheral devices must be installed and configured!
- Access to the Service Mode is protected by the Service Password (see also last page of this manual).
- Inappropriate changes of Service Mode settings may lead to malfunction and errors in the operating sequence!

5.2 Access To Service Mode

The Service Mode is called up by touching the field of the weight display for at least 2 sec.



Service Mode entries are made in the Info-line.



ID: 81154926 / V3.01

Identification-No. of operating system and version of approved software are shown briefly.

Password	????
----------	------



Entry of password (4 digits)



Back to normal operation




Display of ID / MAC address

Wrong password:

Invalid Password!

Repeat entry of password



Service Mode options:



Use arrow-keys left/right to scroll through groups.



Choose displayed group.

Service: Interface

Configure interfaces;
(see chapter 'Interface Configuration')

Service: General

Enter setup parameters: language, format of date, etc.
(see chapter 'Entry Of Parameters')

Service: Calibration

Calibrate scale;
(see chapter 'Calbration Mode')

Service: Config.

Configure scale, digital I/Os, analog outputs
(see chapter 'Configuration')

Service: Test

Test hardware;
(see chapter 'Hardware Test')

Service: Reset

Load factory defaults;
(see chapter 'Reset')

Service: Network

Make network settings;
Note: This menu is only available with network connection.

Service: WLAN

Configure WLAN module;
(see chapter 'WLAN')

Beim Verlassen des Service Mode werden die eingegebenen bzw. geänderten Parameter abgespeichert.

Saving...

Exit Service Mode and store changes, return to normal operation.




CAUTION

Under no circumstances switch off power while 'Saving...' is displayed, because that will inevitably destroy the contents of the Flash-EPROM and thus the program.

6 Configuration

Choose group 'Config.' from Service Mode menu.



6.1 Configure Scale

Config.	Scale
---------	-------

Scale 1	ADM	← →	Enable / disable scale: Select scale driver for first scale: <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">ADM</td> <td>Analog scale base</td> <td></td> </tr> <tr> <td>DWU</td> <td>Mettler-Toledo DigiTOL® loadcells connected to external DigiTOL-Box</td> <td></td> </tr> <tr> <td>SBI</td> <td>MC1 compatible protocol (SBI)</td> <td style="text-align: right;">¹⁾</td> </tr> <tr> <td>Summing</td> <td>Summing scale ADM1 + ADM2</td> <td></td> </tr> <tr> <td>IDNet</td> <td>Mettler IDNet protocol</td> <td style="text-align: right;">²⁾</td> </tr> <tr> <td>xPBI</td> <td>Sartorius IS scale base (digital)</td> <td></td> </tr> <tr> <td>Flintec</td> <td>Flintec protocol</td> <td></td> </tr> <tr> <td>Wipotec</td> <td>Wipotec protocol</td> <td></td> </tr> <tr> <td>Remote</td> <td>Access to scale of an external IT4000E, IT6000E, IT8000E or IT9000E</td> <td></td> </tr> <tr> <td>MT-SICS</td> <td>Mettler-Toldo protocol</td> <td></td> </tr> <tr> <td>Plugin</td> <td>Special scale driver</td> <td></td> </tr> <tr> <td>KERN</td> <td>KERN protocol</td> <td style="text-align: right;">³⁾</td> </tr> <tr> <td>HBM</td> <td>HBM protocol</td> <td></td> </tr> <tr> <td>None</td> <td>Disable scale</td> <td></td> </tr> </table>	ADM	Analog scale base		DWU	Mettler-Toledo DigiTOL® loadcells connected to external DigiTOL-Box		SBI	MC1 compatible protocol (SBI)	¹⁾	Summing	Summing scale ADM1 + ADM2		IDNet	Mettler IDNet protocol	²⁾	xPBI	Sartorius IS scale base (digital)		Flintec	Flintec protocol		Wipotec	Wipotec protocol		Remote	Access to scale of an external IT4000E, IT6000E, IT8000E or IT9000E		MT-SICS	Mettler-Toldo protocol		Plugin	Special scale driver		KERN	KERN protocol	³⁾	HBM	HBM protocol		None	Disable scale	
ADM	Analog scale base																																												
DWU	Mettler-Toledo DigiTOL® loadcells connected to external DigiTOL-Box																																												
SBI	MC1 compatible protocol (SBI)	¹⁾																																											
Summing	Summing scale ADM1 + ADM2																																												
IDNet	Mettler IDNet protocol	²⁾																																											
xPBI	Sartorius IS scale base (digital)																																												
Flintec	Flintec protocol																																												
Wipotec	Wipotec protocol																																												
Remote	Access to scale of an external IT4000E, IT6000E, IT8000E or IT9000E																																												
MT-SICS	Mettler-Toldo protocol																																												
Plugin	Special scale driver																																												
KERN	KERN protocol	³⁾																																											
HBM	HBM protocol																																												
None	Disable scale																																												

¹⁾ Parameters of the Sartorius scale must be set to:
MC1 protocol (SBI), 7 bit, odd parity, 1200 baud, RTS/CTS, streaming mode, 16-character data string.

²⁾ Intended for Mettler-Toledo scale bases with IDNet interface.

³⁾ Intended for KERN scales of series Serien EW and DS.

Not if 'Summing' or 'Remote' was chosen:

Scale 1	ADM1
---------	------



Select scale interface:

ADM1	ADM in socket ADM1
ADM2	ADM in socket ADM2
SIM 1-x	via serial interface
IDN1	IDN in socket ADM1
DWB1	DWB in socket ADM1
DWB2	DWB in socket ADM2

Summing chosen:

Sum 1+2



Choose platforms for summing function:

Sum $1 + 2$
Sum $1 + 3$
Sum $2 + 3$
Sum $1 + 2 + 3$

Remote chosen:

IP 255.255.255.255



Enter IP address of the externally connected weighing terminal.

Port	99999
------	-------

Enter port.

Scale 1	Scale No.	2
---------	-----------	---

Assignment of internal scale to scale of the external weighing terminal:
e.g.: Scale #1 (internal) is assigned to scale #2 of external weighing terminal.

Scale 2	None
---------	------

Continue with next scale,
(if applicable)

Options for setting of scale driver:

[illegible]

6.2 Configure Digital I/Os

The digital inputs/outputs are always configured in groups of 8 inputs and 8 outputs.

Config. Digital IO

Configure I/Os

Group 1: PIM



Configure first group of I/Os, choose connection of digital I/Os:

- PIM Internal I/Os PIM1/PIM2
- REL/TRIO External relay / transistor module
REL485/TRIO485 connected via serial interface
- Modbus TCP To control external I/O modules via Ethernet
- None Not used

REL/TRIO selected:

Group 1: Port SIM1



Assignment to serial interface SIM1 - SIMx

Modbus TCP selected:

IP

Enter IP address for the local net.

Group 2: None

Continue with next I/O group.

6.3 Configure Analog Outputs

Config. Analog out

Configure analog outputs

AOut 1: MAI



Select analog output:

- MAI External analog output module
- DAU8 internal 8-bit analog output module
- DAU15 internal 15-bit analog output module
- None Not applicable

6.3.1 MAI Chosen

AOut 1: Port SIM1   Select pertaining internal serial interface:
SIM1 - SIMx

AOut 1: Address 0   Select pertaining internal address:
Address 0 - Address 7
equivalent MAI Address 16 - Address 23

AOut 1: Module X1   Select external MAI module:
Module X1 - Module X4

AOut 1: Mode 0-10V   Select type of output signal:
0-10V, 2-10V, 0-20mA or 4-20mA

AOut 1: Output Appl.   Select operating mode:
Appl. Controlled by application program
Gross Gross weight
Net Net weight

Gross or Net selected:

AOut 1: Scale 1   Selection of scale for output of gross / net weight.

AOut 1: Calibration N   Calibration of output signal:
N Skip and continue
Y Calibrate output signal, connect multimeter

Calibrate output signal (Calibration = Y):

AOut 1: 0V = 9   Calibrate zero signal, e.g. =0V.
Stepwise increase / decrease analog signal.

AOut 1: 10V = 4095   Calibrate full signal, e.g. 10V.
Stepwise increase / decrease analog signal.

Note: The calibrated values are overwritten when the type of the output signal is changed.

AOut 2: None Continue with next analog output.

6.3.2 DAU15 Chosen

AOut 1: Port SIM1   Select pertaining internal digital interface:
PIM1 - PIMx

AOut 1: Mode 0-10V   Select type of output signal:
0-10V, 2-10V, 0-20mA or 4-20mA

AOut 1: Output Appl.   Select operating mode:
Appl. Controlled by application program
Gross Gross weight
Net Net weight

Gross or Net selected:

AOut 1: Scale 1



Selection of scale for output of gross / net weight.

AOut 1: Calibration N



Calibration of output signal:

N Skip and continue

Y Calibrate output signal, connect multimeter

Calibrate output signal (Calibration = Y):

AOut 1: 0V = 9



Calibrate zero signal, e.g. =0V.
Stepwise increase / decrease analog signal.

AOut 1: 10V = 4095



Calibrate full signal, e.g. 10V.
Stepwise increase / decrease analog signal.

Note: The calibrated values are overwritten when the type of the output signal is changed.

AOut 2: None

Continue with next analog output.

6.4 Configure Analog Inputs

Config. Analog in

AIn 1: MAI



Select analog input:

MAI External analog input module

ADI Internal analog input module

None Not applicable

6.4.1 MAI Chosen

1.MAI: SIM1



Select pertaining internal serial interface:
SIM1 - SIMx

1.MAI: Address 0



Select pertaining internal address:
Address 0 - Address 7

1.MAI: Module X1



Select external MAI module:
Module X1 - module X4

1.MAI: 0-10V



Select input signal:
0 - 10V, 2 - 10V, 0 - 20mA, 4 - 20mA

2.AIn: None

Continue with next analog input.

6.4.2 ADI Chosen

AIn 1: PIM	1	← →	Select pertaining internal digital interface: PIM1 - PIMx
AIn 1: Mode	0-10V	← →	Select input signal: 0-10V, 2-10V, 0-20mA or 4-20mA
AIn 2:	None		Continue with next analog input.

6.5 Configure Fieldbus Module

Config.	Fieldbus		Configure Fieldbus
Fieldbus:Profibus DP		← →	Select Fieldbus connection: Profibus DP Internal Profibus module PBU Modbus TCP Via Ethernet PROFINET Internal PROFINET module PNU Off Not applicable

'Profibus DP' chosen:

Address:	999	Enter slave address
----------	-----	---------------------


7 Calibration Mode

Described below is only the *access* to the calibration mode, for a detailed description of the calibration procedure refer to the following manuals:

- ADM / DUAL-ADM / ADM8000-Exi Calibration Manual, order-No.: ST.2309.0688
- Flintec / HBM Calibration Manual, order-No.: ST.2309.1568
- MultiRange Calibration Manual, order-No.: ST.2309.0057

Described below is only the *access* to the calibration mode.

Prior to power up the jumper W1 must be removed. Only with this jumper setting can the changed parameters be saved in memory after the calibration



In Service Mode call up group 'Calibrate'.

Calibrate Scale 1

←

→

Choose any of the installed scales

F1

Show error protocol of scale

↩

If jumper W1 is still in place:

Calibration Locked

Warning: jumper not in calibration position, parameters cannot be saved!

↩

Enter calibration mode without saving (e.g. to check settings)

Note: Left to the display with the calibration steps, the number of the selected scale is shown [W1], [W2], etc.

After pressing the ↩-key to exit the calibration mode:

Save Parameters ? Y

Save parameters in EEPROM

1
Y(es): Save parameters

0
N(o): Ignore all changes, do not save data

←

→

or scrolling

If jumper W1 on ADM module is still in place:

Error Calibr. Jumper


Error message: jumper not in calibration position, parameters cannot be saved!

↩

Exit calibration without saving

8 Entry Of Parameters (General)

Choose group 'General' from Service Mode menu.



Language: German   Select language:
 German
 English
 Others depending on application program.

All languages except German:

Keyboard: US   Keyboard layout:
 US = US layout
 GB = British layout

Time Zone: CET   Select time zone.
 CET = Central European Time
 Other time zones:
 Canada, EET, EST, Etc, Europe, GB, GMT, HST, MET,
 MST, Mideast, NZ, Pacific, Singapore, UCT, US, UTC,
 WET, Africa, America, Asia, Atlantic, Australia, Brazil
Note: For some entries the particular location must be
 specified, e.g. 'Pacific-Apia'.
 With 'Etc' a time difference to GMT can be chosen.
 Automatic summer / winter time switching is made
 dependent on the chosen time zone.

- ! ATTENTION**
 • After changing the time zone, current time must be entered under menu item 'Settings'
 (see operation manual of application software).

Date: DD.MM.YY   Select format of date:

DD.MM.YY	MM.DD.YY	YY.MM.DD
DD-MM-YY	MM-DD-YY	YY-MM-DD
DD/MM/YY	MM/DD/YY	YY/MM/DD
DD.MM.YYYY	MM.DD.YYYY	YYYY.MM.DD
DD-MM-YYYY	MM-DD-YYYY	YYYY-MM-DD
DD/MM/YYYY	MM/DD/YYYY	YYYY/MM/DD

Time: HH:MM   Select format of date:
 HH:MM HH:MM:SS
 H = hour S = second

Decimal char.: Dot   Select character to separate decimals:
 Dot (e.g. 0.00)
 Comma (e.g. 0,00)

Approval signs: N   Y(es): Weights are printed with approval signs in
 compliance with former PTB regulations:
 Example: Gross/Tare/Net
 <25.45kg> / <10.00kg> / <15.45kg>
 or <25.45kg> / 10.00kgPT / 15.45kgC
 N(o): Weights are printed in compliance with EC
 regulations:
 Example: Gross/Tare/Net
 25.45kg / 10.00kgT / 15.45kgN
 or 25.45kg / 10.00kgPT / 15.45kgN

Tare mode: Gross/Net



Select tare mode:

Gross/Net = press tare key to toggle gross / net display and back;

Auto Clear = on return to the zero range the tare weight is automatically cleared;

Net=0 = every time the tare key is pressed the scale is autotared, on return to the zero range the tare weight is automatically cleared and the display returns to gross mode.

Cont.out: Off



Setting for continuous output:

SysTec SysTec format

Flintec Flintec format

Customized Freely defined format

Sys.Remote RemoteDisplay

Toledo TOLEDO® format

Schauf Schauf format

CAS CAS format

GS Gebhardt&Schäfer protocol with support of traffic light function

Spec1 Customized format

Off Continuous output disabled

Data strings of the continuous output are described in chapter 'Continuous Output'.

Continuous output enabled:

Cont.out: SIM1



Choose serial interface for continuous output:

SIM1 – SIMx

Customized format chosen:

:AAAAAAAAAA

String for freely defined format, see chapter 'Continuous Output'.

Cont.out rate: 99

Enter time in seconds for interval to update the continuous output.

Light Off (Min.) 99


If terminal is not in use, the backlighting is switched off after this time has elapsed (powersave for battery operated terminals). Press any key to switch backlighting on again. Enter 0 to disable this function.

Power Off (Min.) 99

Enter time in minutes after which the terminal is switched off when it is not in use (powersave function for battery operated terminals).

9 Interface Configuration

Choose group 'Interface' from Service Mode menu.



Note: The setting of parameters must correspond to those of the connected peripheral devices.

9.1 Configuration of Ethernet interface

Interface Com0(Eth)



Com0: Port 99999

Enter port

Com0: Protocol None



Select protocol of Com0:

- None Raw data only
- TTY Printer protocol (data only)
- AckNak ACK / NAK procedure with confirmation
- NoAck NO-ACK procedure without confirmation

If TTY was selected as printer protocol:

Com0: Latin 1



Select character set of output:

- None ISO8859 in accordance with chosen language
- 850 DOS Codepage 'Western Europe' (obsolete printers)
- 852 DOS Codepage 'Central Europe'
- 866 DOS Codepage 'Russia'

If AckNak or NoAck was selected as protocol:

Com0:Start Char 999

Entry of start character as decimal value (e.g. 2 = STX)

For entry '0' no start character is transmitted.

Com0:End Char 999

Entry of end character as decimal value (e.g. 3 = ETX)

For entry '0' no end character is transmitted.

Com0:Chksum None



Select method to calculate the checksum which is transmitted behind the end character:

- Chksum None No Checksum
- Chksum XOR Exclusive-Or checksum
- Chksum CPL Complement of two

If a start or end character was specified and a checksum was selected:

Com0:With Start	N	Y	The start character is included in the checksum calculation
Com0:With End	N	Y	The end character is included in the checksum calculation

9.2 Configuration of serial interfaces

Interface Com1(SIM1)	 	Continue with interface Com1
Com1: 9600 Baud	 	Select baud rate of Com1: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200
Com1: 8 Databits	 	Select data format for serial interface Com1: 7 data bits, 8 data bits. Always 1 stop bit is transmitted.
Com1: No Parity	 	Select parity for interface Com1: None Even Odd
Com1: No Control	 	Select hardware handshake for interface Com1: XOn/XOff RTS/CTS None no transmission control
Com1: No Protocol	 	Select protocol of Com1: None Raw data only TTY Printer protocol (data only) AckNak ACK / NAK procedure with confirmation NoAck NO-ACK procedure without confirmation

If TTY was selected as printer protocol:

Com1: Latin 1	 	Select character set of output: None ISO8859 in accordance with chosen language 850 DOS Codepage 'Western Europe' (obsolete printers) 852 DOS Codepage 'Central Europe' 866 DOS Codepage 'Russia'
---------------	---	---

If AckNak or NoAck was selected as protocol:

Com1:Start Char 999

Entry of start character as decimal value
(e.g. 2 = STX)

For entry '0' no start character is transmitted.

Com1:End Char 999

Entry of end character as decimal value
(e.g. 3 = ETX)

For entry '0' no end character is transmitted.

Com1:Chksum None



Select method to calculate the checksum which is
transmitted behind the end character:

Chksum None No Checksum

Chksum XOR Exclusive-Or checksum

Chksum CPL Complement of two

If a start or end character was specify and a checksum was selected:

Com1:With Start N

Y

The start character is included in the checksum
calculation

Com1:With End N

Y

The end character is included in the checksum
calculation

Interface Com2(SIM2)



Continue with following interfaces.

10 Network

Choose group 'Network' from Service Mode menu.

Note: This menu is only available when network connection has been established.

Network settings for Ethernet interface of weighing terminal:

IP 10. 0. 10. 9

Entry of IP address for the local net:

Note: The weighing terminal does not support DHCP and requires a permanent IP address.

Mask 255.255. 0. 0

Entry of subnet mask

DNS 0. 0. 0. 0

Entry of gateway

NTP 255.255.255.255

Example for ptbtime1.ptb.de

Entry of NTP server for time synchronization, this requires entry of time zone.

Applicable only if time zones are supported by the firmware.

FTP Pwd: 9999999

Entry of password for FTP access to the shared directory

Web Access Off



Enable / disable access to data via web browser.

Web Access = On

Web Pwd: 9999999

Specify administrator password

Access No. 99

Max. number of users who may be logged in at the same time.

Terminal-No. 999

Entry of terminal-No. for the network name.


The network name is generated from the terminal type and the terminal-No.

Example: IT8000E_001, IT8000E_123

11 WLAN

Note: Weighing terminals with firmware older than 'Scale_3.9.x' require that the configuration described below must be activated first in the WLAN module, otherwise the parameters entered here do not take effect.

Choose Service Mode group 'WLAN'.



11.1 Configuration

Settings for connection of the WLAN module:

SSID: XXXXXXXXXXXXXXXX	Name of network that is to be connected.						
Type: Ad-Hoc	Select Ad-Hoc or Infrastructure; (depending on local network)						
Ad-Hoc chosen: <table border="0" style="width: 100%;"> <tr> <td style="border: 1px solid black; padding: 2px;">Channel</td> <td style="border: 1px solid black; padding: 2px;">99</td> <td>Select communication channel (standard = 11)</td> </tr> </table>		Channel	99	Select communication channel (standard = 11)			
Channel	99	Select communication channel (standard = 11)					
Security: WPA2	☐ ☐ Encryption method, e.g. WPA or WPA2, (depending on local network, not recommended: WEP)						
WPA2 chosen: <table border="0" style="width: 100%;"> <tr> <td style="border: 1px solid black; padding: 2px;">Encryption: TKIP</td> <td> ☐ ☐ TKIP via TKIP CCMP/AES via AES </td> </tr> </table>		Encryption: TKIP	☐ ☐ TKIP via TKIP CCMP/AES via AES				
Encryption: TKIP	☐ ☐ TKIP via TKIP CCMP/AES via AES						
WPA/WPA2 chosen: <table border="0" style="width: 100%;"> <tr> <td style="border: 1px solid black; padding: 2px;">Change Key: Y</td> <td>Encryption method chosen: Y: activate network password / network key</td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">Key Type: Passphrase</td> <td> ☐ ☐ Passphrase alphanumeric Hex hexadecimal </td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">Key: XXXXXXXXXXXXXXXX</td> <td>Entry of network password / network key</td> </tr> </table>		Change Key: Y	Encryption method chosen: Y: activate network password / network key	Key Type: Passphrase	☐ ☐ Passphrase alphanumeric Hex hexadecimal	Key: XXXXXXXXXXXXXXXX	Entry of network password / network key
Change Key: Y	Encryption method chosen: Y: activate network password / network key						
Key Type: Passphrase	☐ ☐ Passphrase alphanumeric Hex hexadecimal						
Key: XXXXXXXXXXXXXXXX	Entry of network password / network key						
Store Parameter: Y	With Y(es) the settings are stored and the WLAN module automatically performs a reset.						

After successful configuration, the WLAN module works in bridge mode.

11.2 Service

Network settings for the WLAN modul of the weighing terminal:

IP	10.	0.	10.175
----	-----	----	--------

Entry IP address of the weighing terminal for the local net:

Note: The weighing terminal does not support DHCP and requires a permanent IP address.

Mask	255.255.	0.	0
------	----------	----	---

Entry of subnet mask

Gate	0.	0.	0.	0
------	----	----	----	---

Entry of gateway

W.IP	10.	0.	10.176
------	-----	----	--------

Entry of WLAN IP address:

Note: The weighing terminal does not support DHCP and requires a permanent IP address.

This IP address must not be identical to the IP address assigned above, but must be part of the same network.

Store Changes:	Y
----------------	---

With Y(es) the settings are stored and the WLAN module automatically performs a reset.

Notes:

- To recognize the weighing terminal in the network, a gateway must be entered. The syntax of the gateway must correspond to the entered IP address and the subnetmask.
- If the IP address of the WLAN module does not correspond to the address range of the weighing terminal, the error message 'WiPort Unreachable' is output. This message can be acknowledged with Enter/Ok, after that the IP address of the terminal or the WLAN module can be corrected.
- Access to the IP address of the weighing terminal via RTC is possible.

11.3 Reset WLAN

With the function 'Reset' the WLAN module can be reset. The transparent (bridge) is exited and the WLAN module can be configured anew.

Reset WIPort

Y

Y


Reset the WLAN module

Resetting...

- Wait approx. 10 sec while a RESET is performed
- Restart weighing terminal.

Note: Communication via WLAN modul and Ethernet (LAN) is NOT possible at the same time.

11.4 LEDs On The WLX Module



LED	Name	State	Function
V1	WLAN: LINK	On	WLAN switched on
		Off	WLAN switched off
V2	LAN: ACT	On	LAN active
		Off	LAN not active
V5	STATUS: WIP	On	LAN connection
		Off	No LAN connection

12 Test (Hardware)




WARNING

Exercise utmost care when making checks, tests and adjustments that can actuate movable parts such as feeding devices, gates, flaps, conveyors, etc. Make absolutely sure that nobody is within reach of movable parts.

Failure to observe this precaution could result in bodily injury!

Choose group 'Test' from Service Mode menu.



12.1 Test Of Digital Inputs/Outputs

Test: Digital IO



G1 1 In:00000010 Out:00000001

Status information 0 or 1 for the first I/O group. Inputs are shown on the left, outputs on the right hand side. (1 = input/output 'on').

The keys 0 - 7 are used to toggle the outputs 0 to 7.

The picture above shows the state:

input 0, 2-7	= Off	input 1	= On
output 0	= On	output 1-7	= Off

G2 2



Continue with next I/O group (if applicable).

12.2 Test Of Serial Interfaces

Test: Digital IO 

Test: Serial IO



Com1: not ok

Test of serial interfaces (RS232 and RS485-4-wire);
RS232: jump lead from terminal 1 to 3 and from
terminal 2 to 4 (connect RTS with CTS and TxD with
RxD).

RS485.4: jump lead from terminal 1 to 3 and from
terminal 2 to 4 (connect TxD+ with RxD+ and TxD-
with RxD-).

Note: Test of RS485 2-wire and 20mA interfaces is
not possible.

Com2: not ok



Continue with next interface.

13 Reset

With this function values and parameters of the Service Mode can be reset to factory settings. Parameters for calibration and network configuration remain unchanged.

Choose group 'Reset' from Service Mode menu.

13.1 Reset Parameters

Reset Parameters? Y Y Reset parameters of Service Modes.



Resetting...

Group	Setting	Setting
Interface	Com0: Port 1234	Com1: Ctrl. None
	Com0: Protocol None	Com1: Protocol. None
	Com1: Baud 9600	Com1: Start char. 0
	Com1: Databits 8	Com1: End char. 0
	Com1: Parity None	Com1: Checksum None
General	Language: German	Tare mode: Gross/Net
	Date: DD.MM.YY	Cont.out Off
	Time: HH:MM	Light Off (Min.) 0
	Decimal char.: Dot	Power Off (Min.) 0
	Approval signs: N	
Config. Scale	Scale 1: ADM	Scale 2: None
Config. Digital IO	Group 1: PIM	Group 2: None

13.2 Reset Approved Weight



ATTENTION

All records in the W&M approved data archive are irrevocably deleted without further prompt for confirmation.

Reset Approved Wgt Y Y Delete W&M approved data archive



Service: Reset

14 Data Archive

A record -secured with checksum- is stored for every completed weighing transaction in the internal data archive, consisting of weight, date and consecutive Id-No. The Id-No. is reset to 0001 with every change of the date. As an alternative to the internal memory, also a USB stick may be used as data storage device. The stored data are read-only and cannot be deleted or changed.



Call up data archive with display switching key.

Previous / Next	Scroll records
Search date	Enter date of record that is to be looked up
Id-No.	Enter ident-No. of record that is to be logged up
Gross	Gross weight of record
Net	Net weight of record
Tare	Tare weight of record

If an error is detected in the checksum of the data archive, the stored data are void! Instead of a weight, a corresponding error message is shown.

15 Continuous Output

The interfaces COM1 – COMx can be configured as continuous output, one of several protocols can be chosen in group 'General' of the Service Mode. Conflicts of the assignment of peripheral devices must be avoided.

Setting of interface parameters is made in group 'Interface' of the Service Mode.

15.1 SysTec Standard Protocol

The data string consists of 15 ASCII characters plus CR and LF. It includes a status for motion / no motion, the net weight and the unit sign. Digits not used are filled with space characters. Examples:

Digit: '123456789012345'

'S 10.98 t '

'SD 10980 kg'

S = Scale settled (no motion),

SD = Scale in motion (not settled),

13th character always space.

15.2 Flintec Protocol

The data string to connect a Flintec remote display consists of 1 start character (@), 7 ASCII characters for the net weight plus CR. Example:

Char.: '123456789'

'@ 10.95^{C_R}'

1. character always @ (Hex 40)

9. character always CR (Hex D)

non-significant digits of the weight value are transmitted as space characters (Hex 20).

15.3 SysTec Remote Protocol

This data string is used to connect an IT1000 remote display with extended functions.

The operating mode 'Remote Display' must be chosen in the configuration of the IT1000 remote display. Actuating the tare and zero key at the remote display is transmitted back to the weighing terminal and has the same effect as pressing the corresponding key here.

The data string is identical to the 'SysTec Standard Protocol'.

15.4 Schauf Protocol

The data string to connect a Schauf remote display consists of [ESC], [33], [32], 1 space character, 5 ASCII characters for the net weight plus [CR].

15.4.1 Customized Protocol

The data string can be freely defined. In the table below **x** is a wild card. If you want -for instance- to send the character ~ when the scale is in motion, the corresponding string is **M~** (condition = true). If the condition is false, a space character is send instead. Weights are transmitted as shown on the display including decimal separator. Non-significant (leading) weight digits are transmitted as space.

String	Transmission	Example
Mx:y	Transmits the character specified under x , when the scale is in motion , e.g.: ~, else transmits the character specified under y	M~:R
mx:y	Transmits the character specified under x , when the scale is settled , e.g.: R , else transmits the character specified under y	mR:M
Ox:y	Transmits the character specified under x , when the scale is in overload , e.g.: U , else transmits the character specified under y	OU:M
ox:y	Transmits the character specified under x , when the scale is not in overload , e.g.: U , else transmits the character specified under y	oU:M
Zx:y	Transmits the character specified under x , when the scale is in zero range , e.g.: N , else transmits the character specified under y	ZN:M
zx:y	Transmits the character specified under x , when the scale is not in zero range , e.g.: N , else transmits the character specified under y	zN:M
Px:y	Transmits the character specified under x , when the scale is tared , e.g.: T , else transmits the character specified under y	PT:M
px:y	Transmits the character specified under x , when the scale is not tared , e.g.: T	pT:M
[space]	Transmits a space character	[space]
Gx	Transmits the gross weight with x digits, e.g.: 8	G8
Nx	Transmits the net weight with x digits, e.g.: 8	N8
Tx	Transmits the tare weight with x digits, e.g.: 6	T6
U	Transmits the unit of calibration , e.g.: 'kg', 't', 'g', 'lb'	U
R	Transmits the weighing Range , space on single range scales	R1
123	Transmits a specified character (3-digit decimal code)	002 = STX

Example:

String: **'mRN8U013010'**:

This instruction generates a string consisting of the character 'R' when the scale is settled, plus the 8-digit net weight, unit sign and CR, LF.

16 Transport, Maintenance And Cleaning

16.1 Transport

Notes:

- Transport and storage of electronic components such as boards, EPROMS, etc. must only be made in suitable anti-static ESD bags or cases.
- Storage temperature -25 to $+70^{\circ}\text{C}$ at 95% max. relative humidity without condensation.

16.2 Maintenance

! CAUTION

- This unit and its associated equipment must be maintained by qualified personnel only, who are familiar with the construction and operation of all equipment in the system and the potential hazards involved. Failure to observe these precautions could result in bodily injury!

Disconnect all power to this unit before servicing!

The weighing terminal is designed to require a minimum of maintenance and service, however, depending on the environmental conditions a visual inspection at regular intervals is recommended. The frequency at which normal maintenance (cleaning and inspection) should be performed, when installed in a clean office environment, should be twice a year. However, if the unit is subject to a dusty or dirty environment the frequency should be increased as required. At these inspections it should be made sure that all connected cables are undamaged and that all connectors are tightly fastened.

Maintenance of scale platforms is required at regular intervals depending on use and environment. The accuracy of scales can be affected by dirt, foreign objects, etc. and appropriate maintenance is strongly recommended. Also recommended is the calibration with certified test weights at regular intervals.

16.3 Cleaning

! CAUTION

- Disconnect all power to this unit before servicing!

Clean the keyboard and covers with a soft clean cloth that has been dampened with a mild window type cleaner. Do **NOT** use any type of industrial solvent or the finish of the unit may be damaged. Do not spray cleaner directly on the unit.

16.4 Replacing The Battery

! CAUTION


- For the storage of data the weighing terminal contains a lithium battery. Risk of explosion if battery is replaced improperly! Replace only with battery of the same type or with compatible type recommended by manufacturer. Disposal of used batteries only as indicated by manufacturer.

The life time of the lithium battery that backs up RAM and real-time clock is at least three years in normal operation. Thus, the battery needs to be replaced at 3-year intervals by a trained service technician.



WARNING

Disconnect all power to the instrument and/or unplug line cord prior to opening the housing! Failure to observe this precaution could result in bodily injury!



To replace the battery proceed as follows:

- Disconnect all power to the instrument, unplug line cord.
- Open the housing and refer to picture above to locate the mainboard.
- Use small screw driver or other suitable tool and carefully remove bracket from battery holder.
- Carefully remove old battery from holder and insert new one within 30 sec. **Note:** Observe correct polarity as shown on the picture, otherwise the entered data will not be stored!
- Put bracket of battery holder back in place.
- Close housing and power the instrument up. Display of weighing terminal shows power up message. The unit is operational again.

Please note: Observe all applicable regulations for the disposal of used batteries!

17 Trouble Shooting

! CAUTION

- This unit does not contain any customer serviceable parts!

Only permit qualified personnel to service this equipment. Exercise care when making checks, tests, and adjustments!

If any problem arises that has not been explained above, please follow this check list:

- Power supply on and line cord undamaged (visual inspection)?
- All cables connecting to scales and peripheral devices undamaged (visual inspection)?
- Connectors fitted correctly and tightly secured at peripheral devices (visual inspection)?

If operational difficulties are encountered that cannot be rectified by means of this manual, obtain as much information as possible regarding the particular trouble, as this may eliminate a lengthy, detailed checkout procedure.

If possible, try first to determine the conditions under which the problem occurs. Try to find out whether the appearance of the difficulties can be reproduced under the same conditions.

For the systematic analysis of an unknown problem the information as listed below is required:

- Serial-No. of the unit and its peripheral components
- Program version as displayed on power up
- Exact wording of any error message displayed
- Type and model of peripheral devices related to the problem (e.g. scale, printer, etc.)

To obtain professional assistance contact your service station stating the information listed above.

! CAUTION

- It is suggested that assistance from trained service personnel be requested in the event a problem should arise that is beyond the scope of this instruction manual.

17.1 Error Log Of Scale

Calibrate Scale 1

F1 View error log of scale

06.06.12 08:52 Ok

Date, time and error code of event are shown.

Code	Event
Ok	Ok
Over	Overload
Under	Underload
Range	Out of range
Miss.	Not installed
Incl.	Incline sensor
PUOvr	Powerup out of range
PUUdr	Powerup motion
Invalid	Not calibrated
IOErr	I/O error
Not I	Not installed
NotOk	Not ok
E32	Other error message 32

17.2 Error Messages

If an error occurs during calibration or normal operation, error messages are displayed as follows:

Error Message	Possible Cause	Corrective Measure
Calibration Locked	Jumper for protection of calibration parameters in position 'protected'	Set calibration jumper to calibration position
Error Calibr. Jumper	Parameters cannot be saved, jumper in wrong position	Set jumper to correct position, repeat calibration
ADM not installed	No A/D converter installed	Check A/D converter
Not Available	No scale selected	Check parameters in Service Mode
ADM Defect ADM Error	- No data received from A/D converter - Short circuit in L/C cable	- Replace A/D converter - Check cabling
Resolution Error	Internal resolution too small, must be at least tenfold the displayed resolution	- Select bigger increment size - Use L/C with lower capacity
ADM Over Out Of Range	AA/D converter overrange: - Wiring error loadcell - Loadcell defective - Scale heavily overloaded	- Check wiring - Check loadcell - Unload scale

Error Message	Possible Cause	Corrective Measure
W1 ----- Overload	• Scale in overload • CPU does not receive data from weighing interface	• Unload scale • Check internal and external wiring and cabling
Powerup Out of Range	• Error power up zero. This message appears on power up if the weight on the scale exceeds the power up zero range (+2%, +10%) or is below the power up zero range as set in the calibration (-2%, -10%) as set in the calibration.	• Unload scale or apply dead load
Powerup Motion	• This message appears on power up if the terminal cannot detect a settled weight within the specified power up zero range ($\pm 2\%$, $\pm 10\%$).	• Settle scale
Error Transmission	• Host switched off or off-line, data cable not connected or damaged	• Switch on host and start communication program • Check cable and connectors • If problem cannot be rectified, disable data transmission

18 Technical Data

18.1 IT8000ET

Housing	Stainless steel wall/desk housing, protected to IP65, weight approx. 4.2kg Stainless steel panel-mount housing, fascia plate protected to IP65 (when installed accordingly)
Temperature Range	Storage: -25°C to +70°C at 95% relative humidity max. without condensation Operation: -10°C to +40°C at 95% relative humidity max. without condensation
DC Power Supply	Supply voltage U_N : 12V (-15%) – 30 V (+10%) DC Rated Current I_N : 2.2 - 0.6A
Display	Active touch sensitive color TFT, size 152 x 91 mm (7"), 800 x 480 pixel
Processor	32-bit ARM processor, 266MHz Linux operating system
Scale Interface Module	2xADM to connect analog loadcells in 4- or 6-wire mode; W&M approved resolution of 6000 divisions 50 - 400 updates / second Overall impedance of connected loadcells: 43 - 4500 Ω
Battery	Size ½ AA (e.g. Varta 6127); battery backup for data, parameters and files (min. 3 years in normal operation, approx. 1 year when permanently switched off), optional data backup on PC.

Options:


Serial Interface Modules 2 x SIM	SIM-RS232, SIM-RS485-4-wire, SIM-RS485-OPTO, SIM-20mA (only passive / passive), DUAL-ISM
Digital I/O Modules 2 x PIM	2 optoisolated digital inputs (12 - 24VDC / 7 mA) 2 optoisolated digital outputs (12 - 24VDC / 100mA)
Analog Output Module 2 x DAU	1 analog output related to gross or net weight, 0 - 20 mA, 4 - 20 mA, 0 - 10 V, 2 - 10 V selectable
Analog Input Module, 2 x ADI	1 analog input selectable 0 - 20 mA, 4 - 20 mA, 0 - 10 V, 2 - 10 V
Profibus DP Extension Module, 1 x PBU	PBU Profibus DP interface 12 MBit
PROFINET Extension Module, 1 x PNU	PNU PROFINET interface 10 MBit/s, 100 MBit/s
I/O Extension Module 1 x SPU	2 sockets for serial interface modules (SIM) 2 sockets for digital I/O modules (PIM)
WLAN Extension Module, 1xWLX	Connection to wireless local area networks

18.2 ITX000ET External Power Supply Unit


Construction	Aluminum housing for wall-mount / desk-top installation, protected to IP66, weight: approx. 1 kg
Temperature Range	Storage: -25°C to +70°C at 95% relative humidity max. without condensation Operation: -10°C to +40°C at 95% relative humidity max. without condensation
Input:	Input voltage: 110 VAC (-15%) – 240 VAC (+10%) Frequency: 47 - 63 Hz Current consumption: 0.4 - 0.2 A
Output:	Output voltage: 12 VDC Output current: 2.0 A
Electrical Safety	Separation between primary and secondary circuits SELV, in accordance with EN 60950

19 Dimensions


19.1 IT8000ET




Fixing holes




Wall-mount installation




Panel-mount installation



Cutout in panel



19.2 ITX000ET External Power Supply Unit



20 Service Password

The service password is required to access the Service Mode.

The password is: 2234

If you want to prevent unauthorized access to the Service Mode, remove this page from the manual and keep it in a safe place.

If access to the 'Settings' menu of the application program is protected by a *User Password*, also entry of the *Service Password* is accepted. This might be helpful in cases when the User Password is not available any more.

