



SERVICE MANUAL **RAVAS 520**




Rev. 20250114
Printing/Typographical errors and model changes reserved.

Table of Contents

1. Calibration	4
1.1 Preparing for calibration: accurate weighing	4
1.2 Operating key functions of indicator	6
1.3 Display functions	6
1.4 Start calibration procedure: first go into the service menu	7
1.5 Set the scale capacity	8
1.6 Change weigher settings	9
1.7 Go into the calibration menu and perform a zero calibration	10
1.8 Execute weight calibration	12
1.9 Execute level sensor calibration	13
1.10 Set zero	14
1.11 Delete a calibration point	14
 2. Parameter settings	 15
 3. RDC - data transfer	 18

Warning:

Only trained and authorized personnel are allowed to calibrate the scale.





We would like to inform you about the fact that this RAVAS product is 100% recyclable on the basis that the parts are processed and disposed off in the right manner.

More information can be found on our website: www.ravas.com




1. Calibration


1.1 Preparing for calibration: accurate weighing




* excl.



Wrong way of lifting the load



Correct way of lifting the load



Check the zero reading before each weighing!

Before each weighing it is necessary to check whether the system is unloaded and free.

If the indicator does not determine the zero point automatically, it must be done manually using the >0< key.

1.2 Operating key functions of indicator




1.3 Display Functions

kg	Display shows weight in kilograms
lb	Display shows weight in pounds
NET	Display shows net weight
TARE	Display shows tare weight
M	Display shows subtotal memory active
Not level	Make sure the mast is vertical
Bad calibration	no calibration has been done

1.4 Start calibration procedure: first go into the service menu

1

On/ Off
switch



Switch on the indicator by pressing the On/Off button.

2



Press the arrow down 2 times to scroll through the buttons.


3



Press the settings symbol.




4



Now press 'Service Menu'.



5



Enter the password (5220) and confirm with enter.

6




You are now in the service menu.

1.5 Set the scale capacity


It is important to set the scale capacity according to your forklift truck's capacity because some other parameters like zero tracking and display unit will change accordingly.

1



Select 'Weigher' in the service menu.

2



Select 'Settings'. When your system is legal for trade (NTEP) continue with step 3a. Otherwise continue with step 3b.


3a



When your system is legal for trade (NTEP) you have to enter the TAC code.


Confirm with 'Enter'.

3b



Select 'Scale capacity'.

4



Select the correct scale capacity (as shown on the indicator's machine sticker) and confirm with enter.

Scale capacity.

< 2,000 lb	select 2,000
2,001-5,000 lb	select 5,000
5,001-10,000 lb	select 10,000
10,001-20,000 lb	select 20,000
20,001-50,000 lb	select 50,000
50,001-99,000 lb	select 99,000
99,001-200,000 lb	select 200,000

NOTE: If the preferred scale capacity is not in the list, select CUSTOM and enter the capacity you want.

1.6 Change weigher settings

Once you entered the settings in the service menu (via 'Service' - 'Weigher' - 'Settings') there is a scroll down menu from which you can select the setting you wish to change. In total there are 15 different settings to enter, see the pictures (1-3) below.

When you select one of the settings (e.g. unit label, see pictures 1a and 1b), you can change the setting accordingly.


1



2



3



1a



For example: To change the unit label select 'unit label' *

1b




Choose your preference kg or lb and press 'enter'.

*** Note when changing unit label:** The calibration value does not change accordingly. For lb to be displayed you need to perform a new calibration.


1.7 Go into the calibration menu and perform a zero calibration

1




Go into 'service menu', select 'weigher', and select 'Calibration'.

2



Calibrate as suggested by the hand. Start with 'Cal: Zero'.

3



When your system is legal for trade (NTEP) you have to enter the CAL code.


Confirm with 'Enter'.

4




If a calibration is already done, it is indicated by a green check mark in front of a Cal point. When you wish to re-calibrate, select 'Advanced'.

5




Select 'Press 'Calibration reset'.

6




Confirm with 'Ok'.

7



Select 'Number of Cal. points' to select 1 - 4 CAL. points.

8




Select the number of points you wish to calculate. Then press 'Enter' or 'Back'.

9




Select 'Cal:zero' to perform a zero calibration.

10



Select 'Calibrate'.


11



The calibrated signal is now the same as the actual signal.

Press 'Back'.

12




The zero calibration is finished now and marked with a green check mark.

To continue with the weight calibration, see instructions in the next section.

1.8 Execute weight calibration

1




Select 'Cal:weight'.

2



Enter the weight of the load you are going to use for calibration and confirm with 'Enter'.


3



Pick up the load before you start the calibration!

Select 'Calibrate'.


4



The calibrated signal is the same as the actual signal.

Press 'Back'.

5




The weight calibration is now done and marked with a green check mark.

To continue with the level sensor calibration, see instructions in the next section.


1.9 Execute level sensor calibration

1



To calibrate the level sensor select 'Advanced'.


2



Select 'Calibrate level sensor'.


Note: Be sure the mobile weighing system is in horizontal position!

3



Press 'Ok'.

4



Press 'Back' 4x!

The display will show the calibrated weight.

1.10 Set zero

1




When the screen doesn't show zero, set zero manually. Press the zero button.



1.11 Delete a calibration point


Only do this if you wish to re-calibrate.

1




Select the 'Calibration' menu.

2




Select 'Advanced'.

3



Select 'Calibration reset'.

4



Confirm with 'OK'.

2. Parameter settings

Parameter settings for RAVAS 5200			17-12-2018	RAVAS 5200	RAVAS 5200 OMIL
Main menu	Sub menu	Description	Settings	Default	Default OMIL
User menu	Set Time/Date	Time	24.24.24	-	-
		Date	31-12-1999	-	-
Display settings	Brightness	Adjust display brightness	0-100%	100%	100%
	Power save	Switch power save mode on/off	Off/On	off	off
	Keys visible	Switch on/off key functions on the display in weighing mode	Off/On	on	on
	Language	Adjust user language	English/German/French/Dutch	English	English
	Decimal point	Select decimal point	./	-	-
	Date format	Select date format	EU/US	EU	EU
Button Functions	Printer	Function	Print/ Add/ Send/ Abol	Print	Print
		Location	None/ Row1-5/ Button 1-6	None	None
	Send WiFi	Function	Print/ Add/ Send/ Abol	Send	Send
		Location	None/ Row1-5/ Button 1-6	None	None
	Summing	Function	Print/ Add/ Send/ Abol	Add to total	Add to total
		Location	None/ Row1-5/ Button 1-6	Row1/ Button 4	Row1/ Button 4
	Tare	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	Row1/ Button 5	Row1/ Button 5
	Zero	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	Row1/ Button 6	Row1/ Button 6
	ID1 SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None
	ID2 SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None
	ID3 SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None
	ID4 SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None
	PTE SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None
	PTE SCAN	Function	-	-	-
		Location	None/ Row1-5/ Button 1-6	None	None

Communication	Printer settings			
	Live-feed	adjust line feet after print out	0-100	1
	Header	Add header to print out	-	-
	Footer	Add footer to print out	-	-
	BLT 4.0 on-board			
	Protocol	Set the operation protocol	PC	PC
	Info	View BT status	-	-
	RQ232 on-board			
	Protocol	None / PC / Printer / BDC	Printer	Printer
	Stopsbits	Set number of stopsbits	1/2	1
	Disables	Set number of disables	7/8	8
	Parity	Set parity	None / Odd / Even / Mark / Space	None
	Baudrate	Set baudrate	1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	9600
	USB on-board			
	COM 10			
	Port settings			
	Protocol	None / PC / Printer / BDC	None	None
	Scale id	Scale id of which the indicator is known by in the BDC software	automatically according to Ispico board an.	xxx
	Mode Act / Inack	off / on	on	on
	Stopsbits	Set number of stopsbits	1/2	1
	Disables	Set number of disables	7/8	8
	Parity	Set parity	None / Odd / Even / Mark / Space	None
	Baudrate	Set baudrate	1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	9600
	COM 20			
	Port settings			
	Protocol	None / PC / Printer / BDC	None	None
	Scale id	Scale id of which the indicator is known by in the BDC software	automatically according to Ispico board an.	xxx
	Mode Act / Inack	off / on	on	on
	Stopsbits	Set number of stopsbits	1/2	1
	Disables	Set number of disables	7/8	8
	Parity	Set parity	None / Odd / Even / Mark / Space	None
	Baudrate	Set baudrate	1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	9600
Power settings	Power save mode			
	Dim timer	Timer for screen dim function	0-3600 s	60
	Step timer	Timer for indicator in sleep mode	0-3600 s	300
	Deep sleep timer	Timer to set indicator in most energy efficient mode	0-1440 h	8
	Power supply			
	Set the power supply source			
	Track supply / Li-ion 4.8V / 1.2V / 2.0V / Custom			
	Track supply			
	Service key			
	Check calibration	[read only]	-	-
Reset	Auto	View auto hit	-	-
	Error log	Error and overread logging database	-	-
	OML	View OML information	-	-
	Doing	Screens on which sensor input can be checked	-	-
	Software update	Restart indicator in software update mode	-	-
	Reset			
	Reset only the settings, calibration is kept in touch			
	Reset only the calibration, settings are kept in touch			
	Reset Calibration			
	Select the scale type software			
	Hy-Q / HPT			
	Hy-Q			

3. RDC - data transfer using WiFi to PC/server using RAVAS RDC software

In 'SERVICE' / 'COMMUNICATION' / 'COM10 '

Select 'RDC'

- Mode ACK / NACK >>> should be 'ON'
- Scale id >>> here you can enter a 3 digit PIN code

This PIN code is used as scale ID and will be used in the CSV file to determine which indicator has sent the data – please make sure you use a unique number

The RDC software will list this number and at the PC you can enter an alias for this scale nr. (for example: 'Forklift 24').

Note: make sure that your Xpico settings are correct!

In 'Tunnel settings' you need to enter the static IP address of the server and use port number 5555 – see also the Xpico240 or XpicoWi-Fi manual.
