

RAVAS

USER MANUAL

RAVAS indicator 3200

used for:

RPW

RPW-EL/ST

ERGO- scissor/truck

RWV

iForks

RWB

iCP



PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

If you have any queries concerning the duration and terms of the guarantee, please contact your supplier. We would also refer you to our General Sale and Supply Conditions, which are available on request.

The manufacturer accepts no liability for any damage or injury caused by failure to follow these instructions, or from negligent operation or assembly, even if this is not expressly stated in this instruction manual.

In light of our policy of continuous improvement, it is possible that details of the product may differ from those described in this manual. For this reason, these instructions should only be treated as guidelines for the installation of the relevant product. This manual has been compiled with all due care, but the manufacturer cannot be held responsible for any consequences of errors. All rights are reserved and no part of this manual may be reproduced in any way.

We would like to inform you about the fact that this RAVAS product is 100% recyclable on the basis that the parts are processed and disposed of in the right manner.

More information can be found on our website: www.ravas.com



Table of Contents

1. Introduction	4
2. Warning & Safety measures	4
2.1 Lithium Ion Battery	5
3. Schematic overview RAVAS indicator 3200 configurations	7
4. Power supply	8
4.1 Power supply RAVAS indicator 3200	8
4.2 Forklift truck with 6V indicator supply	8
4.3 Forklift truck with converter or stabilizer	8
4.4 Stacker truck and electrical pallet truck supply	8
4.5 Platform with 230V adapter	9
4.6 Power supply transmitter modules	9
5. Configurations of different systems with RAVAS indicator 3200	10
5.1 Electrical pallet truck	10
5.2 Stacker truck	10
5.3 Forklift truck	11
5.4 Platforms	11
6. System startup	12
6.1 Switching on/off the RAVAS indicator 3200	12
7. Changing batteries	13
7.1 Low battery indication RAVAS indicator 3200	13
7.2 Low battery indication transmitter modules indicator 3200-BLE	13
7.3 Changing the batteries of the RAVAS indicator 3200	14
7.4 Changing the battery packs of the transmitter modules	15
7.5 Charging the rechargeable battery packs	15
8. Use	16
8.1 Use (accurate weighing)	16
8.2 Auto shut-off indicator / sleep mode	18
8.3 Indicator functions	19
8.4 Error messages	21
8.5 Net / Tare / Gross weight	22
8.5.1 Net weighing: automatic tare	22
8.5.2 Net weighing: manual tare (PT)	24
8.6 Adding & reset	26
8.7 Entering ID-code	28
8.8 Print out (option)	29
8.9 KG- LB switch	29
8.10 Changing the time and date (on the printout)	30
8.11 User settings	32
8.11.1 User menu explanation list	33
8.12 Supervisor menu (password protected)	34
8.12.1 Supervisor menu explanation list	35
8.12.2 Overview power settings (auto shut-off)	36
8.13 Alibi memory	37
8.14 Relay function - optional	40
9. RAVAS Indicator App	41

1. Introduction




This manual describes the use of the RAVAS indicator 3200. Read this manual carefully. The installer must be informed of the contents of this manual. Always do things in the correct order. This manual should be kept on a safe and dry place. In case of damage or loss the user may request a new copy of the manual from RAVAS.

2. Warning & Safety measures

When using the RAVAS indicator 3200, please observe carefully the instructions and guidelines contained in this manual. Always perform each step in sequence. If any of the instructions are not clear, please contact RAVAS.



- All safety regulations that apply to the truck remain valid and unchanged;
- No weighing operations are allowed if any persons or objects are in the vicinity; around, under or close to the load;
- RAVAS is not responsible for any physical harm done to the operator because of the presence of the indicator in the cabin;
- Any modifications done to the system must be approved in writing by the supplier, prior to any work being completed;
- It is the sole responsibility of the purchaser to train their own employees in the proper use and maintenance of this equipment;
- Do not operate this unit unless you have been fully trained in its capabilities;
- Check the accuracy of the scale on a regular basis to prevent faulty readings;
- Only trained and authorized personnel are allowed to service the scale;
- Always follow the operating, maintenance and repair instructions of this truck and ask the supplier when in doubt;
- RAVAS is not responsible for errors that occur due to incorrect weightings or inaccurate scales.



Should you have any further questions after reading this manual then you can contact us at:

RAVAS Europe B.V.
Veilingweg 17
5301 KM Zaltbommel
Netherlands
Changes reserved.

Phone: +31 (0)418-515220
Internet: www.ravas.com
Email: info@ravas.com

2.1 Lithium Ion Battery (for 3200-BLE transmitter modules)

Important Safety Information



DANGER

- Use the specific Li-ion charger and observe the specified charging conditions when charging the battery.
- Avoid influences of high temperature and keep away from fire.
- Do not deform, modify or disassemble the battery.
- Do not connect the (+) and (-) terminals with metal objects.
- Do not put the battery in (sea) water.
- Do not throw with the battery to avoid strong shocks.



WARNING

- When a battery leaks, the battery should directly be wrapped up properly and treated as recyclable resource.
- When, due to leaking from the battery, liquid gets into your eyes, immediately clean the affected area with water without rubbing your eyes, and seek medical advice immediately.
- The charging of the battery will be stopped automatically. When due to what cause the battery is not fully charged after 8 hours (LED of the charger doesn't become green), immediately unplug the battery from the holder to stop charging. Battery or charger does not work properly, exchange battery or charger.
- Storing and/or using the battery outside the given temperature range may have a negative effect on the lifetime and/or the performance of the battery.
- Do not longer use a battery with leakages, deformation or when any other abnormalities occur.
- Battery should be charged in a dry surrounding.



WARNING

Charging can be carried out at any time regardless of the amount of charge remaining, but you should fully charge the battery at the following moments:

- **The battery is not fully charged at the time of delivery!** The battery can be used after fully charging with the specific Li-ion charger. The LED on the battery charger will become green when fully charged. Note: Before using the weighing system, be sure that the battery is fully charged.
- After the battery has become completely empty. An empty battery will break (loss of capacity) when not directly fully charged.

Specifications

Battery	Operating temperature range
Nominal voltage / capacity	BA-3.7V-5.2A: 5.2 Ah (used for iForks) BA-14.8V-5A: 5 Ah (used for hand pallet trucks)
Operating temperature range	During use: -10°C - +50°C During charging: 0°C - +40°C

Operation

- **Normal charging**
 - Charging takes up to 6-7 hours for a full charge (a partially discharged battery will be fully charged sooner).
 - When the battery is fully charged, charger stops automatically.
 - After charging, the battery should be taken out of the charger.
- **Storing the battery**
 - When the weighing system is not used for a longer period, make sure the battery has approximately 70% of the battery capacity remaining. Take care not to let the battery become completely empty by charging it every 6 months.
 - Store the battery separated from the weighing system in an indoor place (approx. +10°C - +20°C) where it is not exposed to direct sunlight or rain.
- **Battery life**

The battery is a consumable item. The battery will gradually lose its capacity for charging after repeated use and after time has passed. If the operating time that the battery can be used becomes shorter and shorter, it has probably reached the end of its life.

Note: For replacement or additional battery pack, contact your distributor.
- **About used batteries**

Lithium ion batteries are recyclable, valuable resources. For recycling of broken or used batteries, follow the local guidelines in your country. If you are not sure, please send back to the distributor for proper way of recycling.



Disposal information for countries outside the European Union


This symbol is only valid within the European Union. Follow local regulations when disposing used batteries. If you are not sure, consult the place of purchase or a RAVAS dealer.

3. Schematic overview RAVAS indicator 3200 configurations

The RAVAS indicator 3200 is available in two different configurations.

The configuration applicable for **wired** systems is known as the RAVAS indicator 3200 and can be recognized by 'stp1' and 'stp2' on the display.

The configuration applicable for **wireless** systems is known as the RAVAS indicator 3200-BLE and can be recognized by 'F1' and 'F2' on the display.



4. Power supply

4.1 Power supply RAVAS indicator 3200

The **RAVAS indicator 3200** can be supplied internally by 4x AA batteries or externally using the power supply of the truck or using a 230~V adapter. Standard for forklift truck is the internal power solution. Standard for stacker trucks and electrical pallet trucks is the power supply of the truck. Standard for platforms is a 230~V adapter.

4.2 Forklift truck with 6V indicator supply

The indicator has a low-batt indication symbol on the display in the right lower corner. If this symbol is blinking, it is advised to replace the batteries. You may still finish the actual weighing in this stage since the low-batt indication comes 2 minutes before the indicator actually shuts down. See chapter 6 pag. 12 for changing the batteries.

4.3 Forklift truck with converter or stabilizer (option)

For forklift trucks with a combustion engine, a stabilizer board is required. For electrical forklift trucks a converter board is required. The stabilizer or converter board will be built inside the indicator housing. A label is put on the outside of the indicator housing which defines the power supply ranges that can be branched to the indicator power input. Low-batt indication of the indicator is switched off.

NOTE: connecting the indicator to the power of the truck may only be done by qualified personnel!

4.4 Stacker truck and electrical pallet truck supply

Standard the indicators on a stacker truck or electrical pallet truck are powered by the batteries of the truck using a converter board. The converter board is built inside the indicator housing. A label is put on the outside of the indicator housing which defines the power supply ranges that can be branched to the indicator power input. Low-bat indication of the indicator is switched off.

NOTE: connecting the indicator to the power of the truck may only be done by qualified personnel!

4.5 Platform with 230~V adapter

Platforms are normally delivered with a 230~V adapter. The adapter can be ordered with the proper connector for each country but will standard be delivered with the EU connector type plug: C or F. Other plug types need to be mentioned at ordering the unit.

Low-batt indication of the indicator is switched off.


4.6 Power supply transmitter modules (3200-BLE only)

Wireless **RAVAS indicator 3200** uses transmitter modules for transmitting the digital signals of the load cells to the indicator. The transmitter modules come with a Li-ion rechargeable battery and a special battery charging station. Low battery of one of the modules can be detected in the indicator display and on the transmitter module itself.



After an indication of low battery the transmitter module will automatically be switched off after 8 hours. It is recommended to recharge the battery before this period of time has elapsed to prevent unexpected shut down of the system. For changing the batteries and recharging them see chapter 6.

5. Configurations of different systems with indicator 3200


5.1 Electrical pallet truck



5.2 Stacker truck



5.3 Forklift truck




5.4 Platforms

All platforms are delivered with an **RAVAS indicator 3200**. It is not possible to purchase the platform with an **RAVAS indicator 3200-BLE**.

6 System startup

6.1 Switching on/off the RAVAS indicator 3200


ON




Start up the indicator.
Press the on/off key.



OFF





Switch off the indicator
by pressing the on/off
key for 3 seconds.



After 5 seconds all electronics are warmed up and you can start weighing.

*1: For **RAVAS indicator 3200-BLE** the transmitter modules need to be activated as well. Activating the transmitter modules can be done by lifting the forks up and down, or by moving the truck forward and backward. The movement switch will activate the modules. The modules are also being activated upon replacing the batteries. The blinking blue LED indicates if the modules are active or not.



The wireless link between the indicator and the forks will connect automatically.

The iForks are "ACTIVE" when the blue LEDs on both iForks (1 & 2) flash repeatedly.


NOTE: the drawing above gives an example of the transmitter modules used in a forklift truck. Other systems like electrical pallet trucks and stacker trucks will look different but the LED functions similar.

7. Changing batteries


7.1 Low battery indication of the indicator

Exchangeable battery packs supply power to the **RAVAS indicator 3200**.

When the voltage level of the batteries is running low, the low battery indicator will light up. The **RAVAS indicator 3200** will switch off automatically after 2 minutes.



7.2 Low battery indication transmitter modules indicator 3200-BLE



Exchangeable battery packs supply power to the **RAVAS indicator 3200-BLE**.

When the voltage level of the battery packs is running low, the low battery indicator will light up and the pointer of the relating fork - "F1", "F2" or both - will start blinking in the display.

The blue LED (LOW BATTERY) on the relating transmitter module will start blinking very slowly (twice every 10 sec).

The indicator will switch off automatically after 2 minutes. The transmitter module will automatically switch off after 8 hours.

FUNCTIONALITY BLUE LED

DURING POWERING ON

ON for 5 sec.

FULL BATTERY

Blink time interval

Working mode

Once every 1,5 sec.

Sleep mode

Once every 12 sec.


LOW BATTERY

Working mode

Twice every 10 sec.

Sleep mode


Twice every 10 sec.



7.3 Changing the batteries of the indicator (6V version)


The indicator is equipped with 4 AA batteries.

1




Replace batteries as soon as the low battery indicator starts blinking.

2




Remove the battery cover of the indicator housing by turning the screw counter-clockwise.

3




Remove the battery holder and remove the empty batteries.

4



Place new batteries in the battery holder and place the battery holder in the housing. Be sure the batteries are positioned correctly. Check for the polarity!


5



Close the battery cover of the indicator housing and lock by turning the screw clockwise.

7.4 Changing the battery packs of the transmitter modules (RAVAS indicator 3200-BLE only)

Take out both battery packs.



NOTE: The drawing above shows the transmitter modules used in a forklift truck. For other systems the removal of the batteries is similar.

7.5 Charging the rechargeable battery packs



The system is equipped with rechargeable battery packs and a smart charger. After charging for at least 8 hours, the charger will shut off when the battery packs are completely full. The red LED on the adapter will change to green once the batteries are fully charged.

NOTE: It is not necessary to charge both batteries simultaneously. If one battery is charged at a time, the charging time will be shorter.




First position the battery packs inside the charger module, then plug the adapters into the mains voltage.

8. Use


8.1 Use (accurate weighing)



* excl. 



Wrong way of lifting the load



Correct way of lifting the load

Check the zero reading before each weighing!


Before each weighing it is necessary to check whether the system is unloaded and free.

For forklift trucks and stacker trucks it is important to check whether the forks are lifted and not touching the floor before performing a new zero. If the forks are on the floor the indicator will show [-----] in the display with red backlight active.

If the indicator does not determine the zero point automatically, it must be done manually using the >0< key.

8.2 Auto shut-off indicator / Sleep mode

1




20 min. no action!




2

20 sec.




Countdown starts:
Press any key during
countdown to cancel auto-
shut-off and go back to the
weighing mode.

3




Indicator sleep

4




5




Press any key to wake up
the indicator.

8.3 Indicator functions

RAVAS indicator 3200





RAVAS indicator 3200-BLE



	the weighing system (including load) is stable		
	the weight shown is negative	stp/F1	setpoint 1 active (option function key activated)
ZERO	the weight shown is within the zero range	stp/F2	setpoint 2 active (option function key activated)
NET	the display is showing the net weight	kg	displayed weight is in kilograms
e1	displayed weight is in range 1 (option multi range)	lb	displayed weight is in pounds
e2	displayed weight is in range 2 (option multi range)		low bat indicator
e3	displayed weight is in range 3 (option multi range)		

Key functions

Each key has 2 operational and one entry function.

Standard function (short key press)	Key	Special function (long key press)	Value entering function (entry mode)
Zero setting		code entry	enter
automatic tare		pre-set tare	decrease the value of the digit flashing
print weight and add to the total		check subtotal and print/reset total	increase the value of the digit flashing
start special function if active		no function	shift to the next digit on the left
On switch And change to lb and kg		Off switch	clear entry

Important

Operation of a key is not accepted unless the weighing system is stable (and the "load stable" pointer lights up). This means that the indicator only executes commands with a stable load.

8.4 Error messages

ERROR MESSAGES RAVAS indicator 3200


Display	Meaning	Out of error mode
Err01	Load cell signal is unstable	Automatic
Err02	Overload on full scale	Automatic after removing weight
Err03	Gross negative. This action is not allowed	Automatic
Err04	Out of zero range	Press any key
Err06	Input signal too high	Automatic after correcting input
Err08	Calibration out of range (negative)	Automatic
Err09	Calibration out of range (signal too low)	Automatic
Err10	Calibration count 2nd (3rd) point lower than count 1st (2nd) point	Automatic
Err14	Setpoint value 2 < setpoint value 1. This is not allowed	Automatic
CAL-J	Legal for trade version: action not allowed	When action is intended, remove jumper JP1 (attention: after this action a complete new calibration and stamping of the system is necessary)
Err98	Calibration point must be higher than previous one	Automatic
Err99	Action only allowed in start-up units	Automatic
----	Loadcell signal negative	Lift up the forks from the ground
Err_L	Pallet truck is out of level (only legal-for-trade version)	Put the pallet truck into horizontal position
	Battery of indicator is empty	Charge the battery pack
OimL	Action not allowed (only legal for trade version)	Automatic
ntEP	Action not allowed (only legal for trade version)	Automatic
SCALL	Audit trail no out of range	Contact RAVAS Service department
ESoFt	Wrong combination of firmwares	Contact your dealer
EConF	P96 not set	Contact your dealer

ERROR MESSAGES RELATED TO RAVAS indicator 3200-BLE ONLY

Display	Meaning	Out of error mode
ErrF1	Problem with transmitter module 1 (no communication)	Indicator will try to reconnect for 30 sec. Restart indicator. Restart transmitter module and indicator.
ErrF2	Problem with transmitter module 2 (no communication)	Indicator will try to reconnect for 30 sec. Restart indicator. Restart transmitter module and indicator.
Er_F1	too few samples for measurement	Wait for improvement of the wireless connection (by moving the mast to lower position)
Er_F2	too few samples for measurement	Wait for improvement of the wireless connection (by moving the mast to lower position)
tiP	too large load on the tip of forks	Replace load
SidE	too large load on one fork	Replace load
 +F1	battery of transmitter module 1 is empty	Replace the Li-ion pack or recharge
 +F2	battery of transmitter module 2 is empty	Replace the Li-ion pack or recharge
LobaF	Fork batteries are empty (appears after three times start-up with empty batteries)	charge the fork batteries


8.5 Net / Tare / Gross weight

EXPLANATION: $Net(1) + Tare(2) = Gross(3)$




8.5.1 Net weighing: automatic tare


1




2



3




4




The indicator is set to zero.
The "NET" pointer shows that
the tare weight is activated.

5




6



The display shows the net value of the weighed load.

7




8



The gross weight is displayed again.


9




NOTE: for OIML approved RAVAS 3200 the tare will be erased automatically when the weight returns to gross zero! For the next weighing the tare must be activated again.

8.5.2 Net weighing: manual tare (PT)


1




2




3




4




5



6




7




The "NET" pointer lights up.


8




9



10



11



When the pallet wagen is completely unloaded, the tare value is displayed negatively.



12

NOTE: for OIML approved RAVAS 3200 the tare will be erased automatically when the weight returns to gross zero! For the next weighing the tare must be activated again.


Press >T< and then Enter only when tare value is the same.

8.6 Adding & reset

1




2




Press the **TOTAL** key to add the weight load to the total weight.


If a printer is installed, a printout will be made. The gross, net and tare weights are printed.



3




4



The display returns to the weighing mode automatically.

5



6




Press the **TOTAL** key to add the load weight to the total weight.

If a printer is installed, a printout will be made. The gross, net and tare weights are printed.




7

3X







8



The subtotal
can be checked
by pressing the
TOTAL key for
3 sec.

9

3 sec.



= RESET TOTAL & PRINT




= RESET TOTAL

NOTE: In case the total is not manually used or reset, the system will do this automatically as soon as the total number has reached 99 or as soon as the total weight has reached a value of 99999 kg.

8.7 Entering ID-Code

1



> 3 sec.

Press the ID-code key for 3 sec.

2



Last used code is shown (e.g. 20500).
Right digit is flashing.

3a



To accept the old value press Enter.

or: →


3b



Press < to scroll through the digits and press the up or down key until the desired value is reached.



4



The code is activated, the indicator returned to the weighing mode.

Note:

If the code is '00000' it will be ignored and will not be printed on the print out.



To accept the new value press Enter.

8.8 Print out (option)

If the weighing system has been equipped with a printer, obtained and entered weighing data can be printed. Date and time are only printed out with the option board installed.

In the printout a gross weight is indicated with the letters "B/G" and a net weight with the letter "N". A manually entered tare weight will also be printed and is indicated with the letters "PT". The total weight is shown with the letters "TOT".

Standard printout
without code

B/G	1234.5	kg.
T	34.5	kg.
N	1200.0	kg.
*1		
Nr.	1	
10/07/03	17:45	

Standard printout
with code

CODE	12345	
B/G	1234.5	kg.
T	34.5	kg.
N	1200.0	kg.
*1		
Nr.	1	
10/07/03	17:45	


Total printout (always without code)

Tot. B/G	1234.5	kg.
Tot. T	34.5	kg.
Tot. N	1200.0	kg.
*1		
Tot. Nr.	999	
10/07/03	17:45	


*1 Note: in case of a legal for trade unit, the alibi number will be printed here.

8.9 KG- LB switch

1




2



8.10 Changing the time and date (on the printout)

1



10 sec.




The user menu can be entered by pressing the TOTAL key for 10 sec.

2




Press enter to Select.

3




Select "TIME" in the user menu to change the time.

4




Press enter to change the time.

5




The display will show "ho_00" or the previous hour time setting

6



Press the up / down key until the desired value is reached.


7




Press < to change the next digit.




8




Press the up / down key until the desired value is reached.




9



To accept the new value press enter.




10



Repeat the procedure to accept or change:
- the minute setting "m_00"



11




3 sec.



To accept the new setting press enter for 3 sec.



12




Back to weigh mode.




8.11 User settings

1




The user menu can be entered by pressing the TOTAL key for 10 sec.




2



Press enter to Select.



3





These user settings can be changed if desired. See next pages.




a

► EXIT & SAVE



b

► EXIT WITHOUT SAVING




8.11.1 User Menu explanation list

USER menu explanation list				default
User menu	function	remark	settings	1AD
A_OFF	setting of the auto power off function in minutes	setting to 00 means always on (higher power consumption)	00-99	30
BLEId	read out the Bluetooth unique addresses of the slave module on the mainboard or fork module 1/2	scrolling in display when selected	SLAvE/For-1/For-2	SLAvE
Alibi	read out the alibi memory (only for OIML or NTEP systems) by entering the alibi no.	n.a.	n.a.	n.a.
dAtE	setting the date	n.a.	da_xx/m_xx/YE_xx	n.a.
timE	setting the time	n.a.	ho_xx/m_xx	n.a.
bLoFF	selecting the auto off time off the backlight in seconds	setting to 0 means always on (higher power consumption)	0/20/40/80/160/320	20
LiGht	selecting the backlight brightness in %	setting to 0 means always off	0/25/50/75/100/125/150/175/200	100
SLEEP	setting the sleep time in minutes	setting to 00 means never in sleep mode	00-99	20

8.12 Supervisor menu (password protected *)


*1 The Supervisor menu is password protected since version 1.01. Earlier versions of the software are not password protected. For the password please contact RAVAS Service department.

1




The user menu can be entered by pressing the TOTAL key for 10 sec.

2




Press to change to Supervisor menu.

3




Press enter to Select.

4




Select to change the setting.

5




Press enter to Select.

6



Select to change the setting.



8.12.1 Supervisor menu explanation list

SUP(ervisor) menu explanation list				default
Sup menu	function	remark	settings	
BLE	setting the functionality of the Bluetooth port integrated on the mainboard addressed as [SLAVE]	for sub-functions see underneath	PC/ScAn/rEm/Prnt/NonE	PC bidir
rS232	setting the functionality of the RS232 port for wired options	for sub-functions see underneath	PC/ScAn/rEm/Prnt/NonE	Prnt Prot-ASCII LF04 LAYou-Std bArcd-NONE SuPPL-Pr_On
COM3	setting the functionality of the COM 3 port for stacked options	for sub-functions see underneath	PC/ScAn/rEm/Prnt/NonE	NonE
Sub-functions				
PC	selecting the PC functionality	bidir: select if using PC commands from a host PC/Terminal rdc-A: select if using the RDC-application with acknowledgement rdc-N: select if using the RDC-app. without acknowledgement	bidir/rdc-A/rdc-N	bidir
ScAn	selecting the the scanner functionality	not available. Reserved for future use	n.a.	n.a.
rEm	selecting the remote display functionality	select for continuously sending of display values to a RAVAS remote display	n.a.	n.a.
Prnt	select the printer functionality	Prot: select if no. off linefeeds need to be changed LAYou: select if layout needs to be changed bArcd: select if a barcode is required in the print. You may choose to have the net weight, the gross weight or the net and gross weights printed out as a barcode. The values will also be printed out as tekst. After selecting a barcode you need to enter the height of the barcode and the family type Height Family: only 2 family types are available > Barcode 128 and Barcode 39. For printer type XTRA select 128-1 or 39-1, for printer type MPP8250 and 7810v select 128-2 or 39-2. SuPPL: select if the power supply to the printer needs to be changed	0-8 Std/tot NONE/Net/Gross/NETGr	4 Std NONE
NonE	select no functionality for this port			

8.12.2 Overview power settings (auto shut-off)

Overview of Auto shut-off and Sleep settings. The settings mentioned below are the standard settings and advised by RAVAS for optimal use. These settings can be changed in the user menu, as described above.

Auto Shut-off & Sleep Settings									
		RPW-EL 3200 6v	RPW-EL 3200 truck supply	RPW-EL 3200 auto on			RAVAS 3200	RAVAS 3200 Li	
Options -> WiFi / RS / Bluetooth	SLEEP	not possible	0	0	Options -> WiFi / RS / Bluetooth	SLEEP	0	0	
	A_OFF	not possible	0	0		A_OFF	30	30	
No options / Printer 6v	SLEEP	2	30	0	No options	SLEEP	20	20	
	A_OFF	5	0	0		A_OFF	30	30	
									
		iForks 6v	iForks truck supply	iForks auto on			RWV-C truck supply	RWV-C auto on	
Options -> WiFi / RS / Bluetooth	SLEEP	not possible	0	0	Options -> WiFi / RS / Bluetooth	SLEEP	0	0	
	A_OFF	not possible	0	0		A_OFF	0	0	
No options / Printer 6v	SLEEP	2	30	0	No options	SLEEP	0	0	
	A_OFF	5	0	0		A_OFF	0	0	
 									
		RPW-ST 3200 6v	RPW-ST 3200 truck supply	RPW-ST 3200 auto on	RPW-ST- BLE 3200 6v (no printer)	RPW-ST- BLE 3200 truck supply	RPW-ST- BLE 3200 auto on		
Options -> WiFi / RS / Bluetooth	SLEEP	not possible	0	0	not possible	0	0		
	A_OFF	not possible	0	0	not possible	0	0		
No options / Printer 6v	SLEEP	2	30	0	2	30	0		
	A_OFF	5	0	0	5	0	0		
									

8.13 Alibi Memory

The 3200 indicator has the possibility of an alibi memory. The alibi memory will only be used when parameter 13 is set for OIML or NTEP. If parameter 13 is set for 'NONE' the alibi memory will remain unused.

The indicator stores every weighing in its alibi memory and adds a unique number to it. If the alibi memory is activated it will affect the RDC protocol, the PC protocol or the Printer protocol depending on the setting of parameters in the supervisor menu.


The data stored in the alibi memory are:

1. Date > this is the date in format dd/mm/yy (EU) or mm/dd/yy (US).
2. Time > this is the time in format hh:mm.
3. Gross weight > this number always consists of 5 digits, a possible decimal point (as part of the 5 digits), the unit (kg or lb) and the positive or negative sign.
For example: +0233.5kg or -00136.lb.
4. Net weight > this number always consists of 5 digits, a possible decimal point (as part of the 5 digits), the unit (kg or lb), the positive or negative sign and whether it was a calculated net or a measured net.
For example: +0233.5kgC or -00136.lb_. The 'C' stands for calculated and is sent along when a preset tare value was active. If there is no preset tare value active a blanc (space) is put behind the kg (or lb).
5. Tare weight > this number always consists of 5 digits, a possible decimal point (as part of the 5 digits), the unit (kg or lb), the positive or negative sign and whether it was a preset tare or a measured tare.
For example: +0233.5kgP or -00136.lb_. The 'P' stands for preset tare and is sent along when a preset tare value was active. If there is no preset tare value active a blanc (space) is put behind the kg (or lb).
6. Code > this is the 5-digit code that can be entered by keying in. If no code is activated it will show '0'.
7. Alibi number > this is a 4 digit number which is generated by the indicator itself. It will start at '0001' and increase with every weighing up to '9999'. When this number is reached it will start at '0001' again.

The alibi memory is 1Mbit big. It can contain about 7000 weighings. The alibi memory works with FIFO (first in first out). When it becomes full the oldest data will be first overwritten.

For reading out the data saved in the alibi memory please follow next steps:

1



> 10 sec.



The user menu can be entered by pressing the TOTAL key for at least 10 sec.




2



Press enter to Select.




3



Press the up /down key until the display shows the user setting 'ALibi'.




4



Press enter to confirm.




5



Enter the requested alibi number by using the up and down keys and the shift key.
In this example we enter alibi number 2'.




6



Press enter to confirm.




7



The display now shows the date (first day, then month and year) and the time (first hours, then minutes) of the weighing with alibi number 02.

Press enter to continue to the month.

8




Press enter to continue to the year.

9



Press enter to continue to the hour.

10



Press enter to continue to the minute.

11



Press enter to continue.

12

For 0,5 sec the display shows the text 'Gross'.
Next the display shows the gross weight.



Press enter to continue.

- 13** For 0,5 sec the display shows the text 'Net' or 'Net_C'.
Next the display shows the net weight.
Net: weight is measured.
Net_C: weight is calculated.




Press enter
to continue.

- 14** For 0,5 sec the display shows the text 'tArE' or 'PtArE'.
Next the display shows the tare weight.
tare: weight is measured.
Ptare: weight is keyed in.




Press enter
to continue.

- 15** For 0,5 sec the display shows the text 'Code'.
Next the display shows the code used. If
no code was used the display shows '0'.



The indicator will automatically
return to the user setting 'Alibi'
in the user menu.

- 16**



Press enter to search for another
weighing or press 'CLR' 2x to return to
the normal weighing mode.

8.14 Relay function - optional

The 3200 indicator has the possibility to setup limit values for relay settings. The different options for relay settings are:

- overload on gross weight
- overload on net weight
- dosing / filling with manual tare & start
- dosing / filling with automatic tare & start

For the setup and activation of the relay settings please contact RAVAS Service department.

9. The RAVAS Indicator App

The RAVAS Indicator App is designed for efficient data collection from RAVAS weighing systems. Whether used as a stand-alone solution or integrated with RAVAS RDC software, the Indicator App offers flexible integration to suit your operational needs. By streamlining weighing and labeling processes, it helps you save time and reduce errors, boosting overall productivity.



Standard version:

► Mobile data collection

Capture and store all weighing data directly on your mobile device for easy management on the go.

► Comprehensive data logging

Record all weighing data, including date and time, for precise tracking and reporting.

► Seamless data transfer

Quickly send data to a PC via email using wireless connectivity for efficient communication.

Full version:

► Real-time QR code display

Display weight data as a QR code for instant access and sharing.

► Custom label printing

Print customized labels with added fields and text for enhanced labeling options.

The standard version of the RAVAS Indicator App with limited functionalities can be downloaded for free from Google Play.

The full version is available through RAVAS for a 1-year or 5-year license period.

