INDICATOR 6100

Weight indicator with programmable scale functions



BENEFITS

- Advanced parts counting function
- Programmable for customer applications
- Alphanumeric keypad
- RS232, RS485, 4-20 mA, 0-10V output

Top quality
Customised functions









INDICATOR 6100

FUNCTIONS

- Automatic and manual zero correction
- Gross/net weighing
- Automatic tare by push button
- Tare entry via numerical keypad
- Internal memory for 9 pre-set tare values
- Totalling function
- Piece counting by sampling or entering of piece weight
- Alphanumeric code entry (max. 10 characters), via keypad
- Internal clock (for recording date/time on printout)
- Error messages in display
- Power supply to printer switched on and off by indicator
- Low battery indication
- Different basic functionality programs available (e.g. dosing program)

STANDARD SPECIFICATIONS

Display digital, alphanumeric

Segments
 Graduation
 LCD, digit height 14 mm, backlight
 0.1, 0.2, 0.5, 1, 2, 5, 10, 20 or 50 kg
 see specifications weighing system)

Housing stainless steel

Power supply
 12V (230V for stationary applications)

IP65 / NEMA 4

Power consumption 170 mA

Protection class

Dimensions excl. cable glands: 225 x 190 x 45 mm







Management System ISO 9001:2015 ISO 14001:2015 ISO 45001:2018 www.tuv.com

OPTIONS*

- Customer specific print lay out
- Customer specific software (Touch)
- Bluetooth or WLAN output
- Printer output to thermal or matrix printer
- Extra data output (RS232, RS485, 20 mA CL passive, 4-20 mA (32500 divisions), 0-10V passive)
- Relay switch, for automatic dosing (two setpoints)
- Barcode scanner/printer (Touch)
- Reference scale, for accurately determining small piece weights
- Explosion proof version (EXd)

RAVAS Europe B.V.

Veilingweg 17, 5301 KM Zaltbommel, The Netherlands T: +31 418 515220 E: salesoffice@ravas.com

WWW.RAVAS.COM

