

Using REST full API to connect to RAVAS scales

RAVAS 3200 indicator with Wi-Fi module inside, using static IP addresses.

WMS sends REST full commands to RIS application.
RIS sends ASCII commands to the RAVAS indicators.

