

RCS Plus - after October 2018

Nr.	Item code	Description	Special instructions	Quantity
D16	SAP-HOP-RAV-RAL3000-UPPER	Subassembly, Housing upper RAL3000 (incl. bolts and rings)	Also order the touch panel needed for your system	1.0
D17	FR-31N-RAV-HO-RCS-PLUS	Front panel 3100N RAVAS housing, RCS Plus		1.0
D18	IN-31-N-ADS-RCS+-0213	Indicator 3100 N ADS RCS application		1.0
D19	EB-31-N-PRINTER-RS232-6V/12V	Option board 3100 N printer RS232 isolated		1.0
D20	SA-HOP-RAV-RAL9011-LOWER	Subassembly, Housing lower part ECO black RAL 9011	Only used for 12v versions	1.0
D23	SA-MP-SUP-RAM-CLAMP-BASE	Subassembly, RAM-support clamp		1.0
D25	EB-CON-9/100V-12V-ISOLATED	Converter 9/100v 12v isolated		1.0
D27	MP-BRACKET-RAM-BB	Bracket RAM BB, RAL7021		1.0
D28	MP-BRACKET-RAM-PR-TH-7810	Bracket RAM Martel printer 7810V	Option: printer	1.0
D30	PR-EXT-TH-RAVAS-7810V	Printer Thermal 7810V	Option: printer	1.0
D31	PRP-CA-EXT-TH-RAVAS	Cable printer Custom S /+ 7810 V	Option: printer (power and data cable)	1.0
D57	EP-FUSE-3,15A	Fuse 5x20 3,15A		1.0
D58	EP-FUSE-HOL-FL	Fuse holder floating		1.0

Nr.	Item code	Description	Special instructions	Quantity
D61	LC-ROS-PT404-TC	Oil pressure sensor PT404 TC	with cable length 6m	1.0
D88	PRP-PAP-TH-RAVAS-58-32-12	Printer paper APS	Option: printer	3.0
D103	SA-IN-31-RCS-+-RAL3000-CONV	Subassembly, i3100 RCS+, RAL3000, 9/100V-12V (ind. only)		1.0
D103	SA-IN-31-RCS-+-RAL3000-P	Subassembly, i3100 RCS+, RAL3000, printer (ind. only)		1.0
D138	EB-31-N-RCS+	Electronic board 3100 N, for RCS+, with valve output		1.0
D139	HW-MANIFOLD-10T	Manifold block RCS plus		1.0
D140	HW-VALVE	Magnetic valve RCSplus		1.0
D141	HW-VALVE-FLOW	Flow valve RCSplus		1.0
D142	HW-VALVE-PLUG	Valve plug RCS plus	Connected to electronics board (D138) by 2 core cable (CA-2-0,75-FLAT)	1.0
D143	HOP-SPACERRING	Spacer ring RAVAS housing		1.0
D185	HW-CAP-VALVE-FLOW	Cap flow valve RCSplus		1.0