

RAVAS-4100 EX

Nr.	Item code	Description	Special instructions	Quantity
D3	LC-1000-M-350	Load cell 1000 M 350	Serial number is needed when ordering this compoment. Mandatory for legal for trade systems.	4,0
D4	SAP-MP-BOLT-M12-40-CYL	Subassembly, Bolt M12 x 40 socket head, 8 pieces		8,0
D5	MP-BOLT-M12-60-CS-STST	Bolt M12 x 60 countersunk stainless steel din7991, A2	Needed for stainless steel ssytems or systems with stainless steel fork shoes	4,0
D7	SAP-MP-NUT-M12-LOCKNUT	Subassembly, Nut M12 locknut, 4 pieces		4,0
D8	BA-EX-BU10-STST	Battery pack EX stainless steel (BU10)		1,0
D54	CO-EX-BU10	Connector EX battery BU10		2,0
D75	PT-H-RAL3000	Pallet truck Hu-lift red RAL3000, quicklift		1,0
D77	PTP-H-HAN-RAL5012	PT-H handle for pallet truck RAL 5012	For systems with the Hu-Lift chassis	1,0
D78	PTP-WH-ST-AS-180	PT wheel steering anti-static Ø180 mm		2,0
D79	PTP-H-WH-TL-PU-LOOSE	PT-H Tandem wheel loose (H1)		4,0
D80	PTP-H-REP-QUICKLIFT	PT-H Repair kit for Quicklift pump	For systems with the Hu-Lift chassis	1,0
D81	FS-H+N+R-STST	Fork shoes HU + Noble + Ruyi stainless steel - bead blasted	Option: stainless steel fork shoes	1,0
D94	MP-MP-4	Mounting plate load cell 4 mm		12,0

Nr.	Item code	Description	Special instructions	Quantity
D95	MP-RING-M12	Ring M12, din125A		4,0
D134	SA-HO-JUNC-EXI	Subassembly, Junction box for EX systems	Includes calibration board EB-4-LC-21-41	1,0
D153	PTP-H-BRAKE-FO-QUICK	PT-H Footbrake Quicklift		1,0
D157	SA-CH-12V-1A	Subassembly, charger, 12v 1A, EU/UK/US		1,0
D157	CH-12V-1A	Charger 12V-1A		1,0
D157	SA-CH-12V-1A-BU10-EX	Subassembly, charger, 12v 1A for EX BU10 battery		1,0
D236	MP-MP-STST	Mounting plate stainless steel (adaptor plate)		1,0
D261	SAO-I41-EX-XTRA-RAL3000	Subassembly, EX 4100 XTRA, RAL3000		1,0
D262	PTP-H-PS-STST	PT-H Pallet stop HU-chassis, stainless steel		1,0
D263	PTP-H-PUMP-QL	PT-H Pump quicklift assembly rubber tank		1,0