

ProLine Touch

Nr.	Item code	Description	Special instructions	Quantity
D3	LC-1000-M-350	Load cell 1000 M 350	Serial number is needed when ordering this compoment. Mandatory for legal for trade systems.	4.0
D4	MP-BOLT-M12-40-CYL	Bolt M12 x 40 socket head D912 8.8		8.0
D5	MP-BOLT-M12-60-CS	Bolt M12 x 60 countersunk din7991, 10.9		4.0
D7	MP-NUT-M12-LOCKNUT	Nut M12 lock nut din985		4.0
D8	SA-BA-RAV-6V-RC	Subassembly, Battery ProLine, rechargeable		4.0
D15	SAO-CH-DUAL-N2	Subassembly, charger iFork, N2 version		1.0
D15	SA-CH-DUAL-N2-UK	Subassembly, charger iFork, UK plug, N2		1.0
D15	SA-CH-DUAL-N2-US	Subassembly, charger iFork, USA plug, N2		1.0
D51	CA-2-0,75-FLAT	Cable 2x0,75 flat - per meter		1.0
D75	PT-A-RAL3000	Pallet truck Almeborg 1150x550, RAL 3000		1.0
D76	PTP-A-PUMP	PT-A Pump		1.0
D77	PTP-A-HANDLE	PT-A Handle complete Almeborg chassis, standard version		1.0
D78	PTP-A-WH-ST-RUB	PT-A wheel steering Rubber (std wheel)		2.0

Nr.	Item code	Description	Special instructions	Quantity
D78	PTP-A-WH-ST-PU	PT-A wheel steering Polyurethane	Option: polyurethane steering wheels	2.0
D79	PTP-A-WH-TL-PU-82MM-LOOSE	PT-A wheel tandem loading polyurethan, 82mm, painted chassis		4.0
D79	PTP-A-WH-TL-NYL-82MM-LOOSE	PT-A wheel tandem loading nylon, 82mm, painted chassis		4.0
D80	PTP-A-REP	Repair kit for painted/semi stainless hand pallet truck		1.0
D81	FS-A-RAL9005	Fork shoes Almeborg RAL9005		1.0
D87	PR-INT-TH-RAVAS-MPP8250	Printer MPP8250	Option: printer	1.0
D88	PRP-PAP-INT-TH-RAVAS	Printer paper for Plus/S/MPP8250 thermal printer	Option: printer	3.0
D91	EB-4-LC-21-41	Junction board 4xLC		1.0
D92	SAO-EP-LEVELSWITCH-C3041	Subassembly, Levelswitch with C3041chip	Option: legal for trade	1.0
D95	MP-RING-M12	Ring M12, din125A		4.0
D98	HO-HI-END-BH-RAL3000	Bottom housing, Hi-end palletwagen, RAL3000		1.0
D100	HOP-MP-U-HI-END-RAL3000	Mounting part High End bottom housing universal RAL3000		1.0
D103	IN-TOUCH	Indicator Touch		1.0
D106	SA-HO-SYN-JUNCTION	Subassembly, Junction box with bolts and screws		1.0
D116	SAP-MP-LC-FLEXIBLE-V5	Subassembly, Load cell flexbolt with M8 nut		2.0
D117	HOP-LOCK-PRO	Lock Pro		1.0

Nr.	Item code	Description	Special instructions	Quantity
D119	SAP-MP-BASE-ROTATING	Subassembly, set rotating base indicator (incl bolts)	Option: rotating indicator	1.0
D123	HOP-CP-HI-END-BH-RAL3000	Coverplate High end Housing RAL3000		1.0
D123	HOP-CP-HI-END-BH-RAL3000-PLUS	Coverplate High end Housing RAL3000 Plus		1.0
D128	HOP-MC-HI-END-RAL9005	Middle cover High End RAL9005		1.0
D129	MP-JUNC-HI-END-STST	Mounting plate junction box High End stainless steel		1.0
D131	SAP-BAP-HOLDER-PROLINE	Subassembly, Battery pack holder ProLine (incl. 2x bolt)		4.0
D152	MP-WF-BUSH-LC	Bush load cell holes RWV-N		8.0
D153	PTP-A-BRAKE-FO	PT-A Foot brake for painted chassis (Almeborg)	Option: foot brake	1.0
D213	MP-SUP-IN-TOUCH-ROT-STST	Mounting support Touch		1.0
D220	EB-BOA-RELAY-12V	Board relay 12V		1.0
D221	MP-IT3/8-RELAIS	Mounting bracket relay board IT3000/8000		1.0