

RAVAS-5200-F Li

Nr.	Item code	Description	Special instructions	Quantity
D3	LC-1000-350-MR	Load cell 1000, 350 Ohm, multi-range		4.0
D3	LC-1000-M-1000	Load cell 1000 M 1000 Ohm	Serial number is needed when ordering this compoment. Mandatory for legal for trade systems.	4.0
D4	MP-BOLT-M12-40-CYL	Bolt M12 x 40 socket head D912 8.8		8.0
D5	MP-BOLT-M12-60-CS	Bolt M12 x 60 countersunk din7991, 10.9		4.0
D7	MP-NUT-M12-LOCKNUT	Nut M12 lock nut din985		4.0
D8	SA-BA-RAV-LI	Subassembly, Battery pack Li-ion, with handle		1.0
D15	SA-CH-RAV-LI	Subassembly, charger station RAVAS Li-ion battery pack		1.0
D15	SA-CH-RAV-LI-US	Subassembly, charger station RAVAS Li-ion battery, USA plug		1.0
D15	SA-CH-RAV-LI-UK	Subassembly, charger station RAVAS Li-ion battery, UK plug		1.0
D56	EB-52-1AD-LC	AD board for load cell systems, i5200		1.0
D59	HOP-RING-RUB-52-RAV-RAL3000	Red ring housing 52		1.0
D65	SAO-IN-52-UPPER-M	Subass., indicator 52 in upper housing, incl. OIML AD board	Option: legal for trade	1.0
D66	SA-HOP-LOWER-52	Subassembly, Housing 52 lower part incl. grommet		1.0

Nr.	Item code	Description	Special instructions	Quantity
D75	PT-H-RAL3000	Pallet truck Hu-lift red RAL3000, quicklift		1.0
D76	PTP-H-PUMP-RIBS	PT-H Pump assembly ribs (CA)	For systems with the Hu-Lift chassis	1.0
D77	PTP-H-HAN-RAL5012	PT-H handle for pallet truck RAL 5012	For systems with the Hu-Lift chassis	1.0
D78	PTP-H-WH-ST-RUB	PT-H steering wheel rubber (F)	For systems with the Hu-Lift chassis	2.0
D79	PTP-H-WH-TL-PU	PT-H set loading wheel tandem polyurethane yellow	For systems with the Hu-Lift chassis	2.0
D80	PTP-H-REP-QUICKLIFT	PT-H Repair kit for Quicklift pump	For systems with the Hu-Lift chassis	1.0
D81	FS-H-RAL3000	Fork shoes WHPT red RAL 3000		1.0
D87	PR-INT-TH-RAVAS-MPP8250	Printer MPP8250	Option: printer	1.0
D88	PRP-PAP-INT-TH-RAVAS	Printer paper for Plus/S/MPP8250 thermal printer	Option: printer	3.0
D89	PRP-CA-INT-MX-RAVAS	Printer cable Able	Option: matrix printer	1.0
D90	PRP-RIB-RAVAS	Ribbon cassette	Option: matrix printer	1.0
D91	EB-4-LC-21-41	Junction board 4xLC		1.0
D92	SAP-EP-LEVELSENSOR	Subassembly, Level correction sensor (incl. 2x bolt + ring)	Option: legal for trade	1.0
D94	MP-MP-4	Mounting plate load cell 4 mm		12.0
D95	MP-RING-M12	Ring M12, din125A		4.0
D103	SA-IN-52	Subassembly, indicator 5200, HPT version, (ind. only)		1.0

Nr.	Item code	Description	Special instructions	Quantity
D103	SA-IN-52-M	Subassembly, indicator 5200, HPT M version, (ind. only)	Option: legal for trade	1.0
D105	SA-HO-BAT-WF-LI	Subassembly, housing battery pack Li-ion		1.0
D106	SA-HO-SYN-JUNCTION	Subassembly, Junction box with bolts and screws		1.0
D110	HO-BH-FLAT-52-RAL9005	Bottom housing 52, flat, RAL9005		1.0
D111	HOP-CO-PR-52-RAL9005	Cover printerhole housing 5200 RAL9005		1.0
D112	MP-BASE-ROTATING-STST-V2	Rotating base indicator stainless steel, version 2		1.0
D113	MP-BRACKET-TILT-ROT-5200-STST	Tilt bracket top 5200 for V2 rotating base, stainless steel		1.0
D114	MP-BRACKET-TILT-ROT-V2-STST	Tilt bracket bottom for V2 rotating base, stainless steel		1.0
D115	MP-KNOB-M6-32	Knob M6 x 32		1.0