

RAVAS-320

Nr.	Item code	Description	Special instructions	Quantity
D3	LC-1000-M-1000	Load cell 1000 M 1000 Ohm	Option: legal for trade	4.0
D4	MP-BOLT-M12-35-CYL	Bolt M12 x 35 socket head DIN 912 8.8		8.0
D5	MP-BOLT-M12-55-CS	Bolt M12 x 55 countersunk 7991, 8.8		4.0
D7	MP-NUT-M12-LOCKNUT	Nut M12 lock nut din985		4.0
D8	SA-BA-RAV-LI	Subassembly, Battery pack Li-ion, with handle		1.0
D15	SA-CH-RAV-LI-US	Subassembly, charger station RAVAS Li-ion battery, USA plug		1.0
D17	FR-32-RAV-PT	Front panel 3200 RAVAS pallet truck		1.0
D18	IN-32	Indicator 3200		1.0
D19	EB-32-1AD-M	ADC expansion module M, i3200	Option: legal for trade	1.0
D75	PT-N-RAL1028-RAL9005-USA	Pallet truck Noblelift yellow, black fork shoes usa 690x1220	For systems shipped from August 2020	1.0
D75	PT-H-RAL3000-USA	Pallet truck Hu-lift red RAL3000 usa 690x1200	For systems shipped before August 2020	1.0
D76	PTP-N-PUMP-QUICKLIFT	PT-N Pump with quicklift	For systems with the Noblelift chassis	1.0
D76	PTP-H-PUMP-RIBS	PT-H Pump assembly ribs (CA)	For systems with the Hu-Lift chassis	1.0

Nr.	Item code	Description	Special instructions	Quantity
D77	PTP-N-HANDLE	PT-N Handle complete , standard version	For systems with the Noblelift chassis	1.0
D77	PTP-H-HAN-RAL5012	PT-H handle for pallet truck RAL 5012	For systems with the Hu-Lift chassis	1.0
D78	PTP-N-WH-ST-RUB	PT-N Wheel steering rubber (309+310)	For systems with the Noblelift chassis	2.0
D78	PTP-H-WH-ST-RUB	PT-H steering wheel rubber (F)	For systems with the Hu-Lift chassis	2.0
D79	PTP-N-WH-LO-PU	PT-N Wheel loading polyurethane	For systems with the Noblelift chassis	2.0
D79	PTP-H-WH-TL-PU	PT-H set loading wheel tandem polyurethane yellow	For systems with the Hu-Lift chassis	2.0
D80	PTP-N-REP	PT-N Standard pump repair set	For systems with the Noblelift chassis	1.0
D80	PTP-H-REP-QUICKLIFT	PT-H Repair kit for Quicklift pump	For systems with the Hu-Lift chassis	1.0
D81	FS-N-RAL9005-USA	Fork shoes Noblelift RAL9005, USA	For systems with the Noblelift chassis	1.0
D81	FS-H-RAL3000-USA	Fork shoes WHPT red RAL 3000, USA	For systems with the Hu-Lift chassis	1.0
D82	MP-BRACKET-ADA-21-PIN	Adapter bracket 2100 +pin		1.0
D83	MP-BRACKET-IN-21-41-LOW	Indicator bracket 2100 / 4100 low		1.0
D84	HOP-CP-RAV	Coverplate RAVAS		1.0
D85	SA-HOP-RAV-GREY-LI	Subassembly, parts for grey savar housing, Li-ion battery		1.0
D86	HO-SHIELD-FLAT-RAL3000	Shield RAVAS chassis red RAL3000 flat bottom		1.0
D87	PR-INT-TH-RAVAS-MPP8250	Printer MPP8250	Option: printer	1.0

Nr.	Item code	Description	Special instructions	Quantity
D88	PRP-PAP-INT-TH-RAVAS	Printer paper for Plus/S/MPP8250 thermal printer	Option: printer	3.0
D91	EB-4-LC-N-21-41	Junction board 4xLC N		1.0
D92	SAP-EP-LEVELSENSOR	Subassembly, Level correction sensor (incl. 2x bolt + ring)	Option: legal for trade	1.0
D93	SA-IN-32-LI-M	Subassembly, savar 3200, for Li-ion battery, M	Option: legal for trade	1.0
D93	SA-IN-32-LI-M-P	Subassembly, savar 3200, for Li-ion battery, M, printer	Option: legal for trade; thermal printer	1.0
D94	MP-MP-6	Mounting plate load cell 6 mm		4.0
D95	MP-RING-M12	Ring M12, din125A		4.0