



nr.	Item code	Description	Special instructions	Quantity
D25	EB-CON-9/100V-12V-ISOLATED	Converter 9/100v 12v isolated		1.0
D28	MP-BRACKET-HYQ-52-PR-TH-7810	Bracket RCS Hy-Q 52 Martel printer 7810V		1.0
D30	PR-EXT-TH-RAVAS-7810V	Printer Thermal 7810V	Option: printer	1.0
D31	PRP-CA-EXT-TH-RAVAS	Cable printer Custom S /+ 7810 V	Option: printer	1.0
D33	EB-OPT-WIFI-XPICO240	Option board WIFI, Xpico 240		1.0
D34	EP-ANTENNE-WLAN-UFL	Antenne WLAN, UFL connector		1.0
D35	EB-OPT-N2-BLT-4.0-CLASSIC	Option board bluetooth 4.0 classic		1.0
D51	CA-2-0,75-FLAT	Cable 2x0,75 flat - per meter		5.0
D52	CA-3-0,5-PUR-BLACK	Cable 3 x 0,5 PUR black - per meter		5.0
D53	CAP-PROTECTION-CURLY	Curly cable protection - per meter		1.5
D54	CO-3P-F-CA	Connector 3-pins female cable		1.0
D55	CO-3P-M-CA	Connector 3-pins male cable		1.0
D56	EB-52-1AD	AD board, i5200		1.0

nr.	Item code	Description	Special instructions	Quantity
D57	EP-FUSE-3,15A	Fuse 5x20 3,15A		1.0
D58	EP-FUSE-HOL-FL	Fuse holder floating		1.0
D59	HOP-RING-RUB-52-RAV-RAL3000	Red ring housing 52		1.0
D60	MP-RING-MANI-M13	Ring manifold M13		1.0
D61	LC-ROS-PT404-TC	Oil pressure sensor PT404 TC		1.0
D62	SA-MP-BRACKET-CONTACTS-RCS-HYQ	Subassembly, Bracket with reed contacts incl. conn. RCS Hy-Q		1.0
D63	SA-MP-BRACKET-MAG-RCS-HYQ	Subassembly, Bracket magnet RCS Hy-Q		1.0
D64	SA-MP-SUP-RAM-CLAMP-SQUARE	Subassembly, RAM-support clamp with square base		1.0
D65	SAO-IN-52-UPPER	Subassembly, indicator 52 in upper housing		1.0
D66	SA-HOP-LOWER-52	Subassembly, Housing 52 lower part incl. grommet		1.0
D88	PRP-PAP-INT-TH-RAVAS	Printer paper for Plus/S thermic	Option: printer	1.0