



RAVAS-2100L Exi

Nr.	Item code	Description	Special instructions	Quantity
D0	HOP-KEY-EXI	Key housing EXi		1,0
D3	LC-1000-M-350	Load cell 1000 M 350	Serial number is needed when ordering this compoment. Mandatory for legal for trade systems.	4,0
D4	MP-BOLT-M12-40-CYL-STST	Bolt M12 x 40 socket head stainless steel DIN 912		8,0
D5	MP-BOLT-M12-60-CS-STST	Bolt M12 x 60 countersunk stainless steel din7991, A2	Needed for stainless steel ssytems or systems with stainless steel fork shoes	4,0
D7	MP-NUT-M12-LOCKNUT-STST	Nut M12 lock nut stainless steel din985 A2	Needed for stainless steel ssytems or systems with stainless steel fork shoes	4,0
D8	BA-EXI	Battery pack EXi		1,0
D15	SAO-CH-EXI	Subassembly, charger EXi		1,0
D17	FR-21-TOUCH-PANEL	Front panel 2100 - touch panel		1,0
D18	IN-21-NU-EXI-R76-P7.8	Indicator 2100 NU EXi R76, P7.8 version	Option: Legal for trade	1,0
D75	PT-R-RAL3000	Pallet truck Ningbo Ruyi RAL3000 quicklift		1,0
D76	PTP-R-PUMP	PT-R Pump		1,0
D77	PTP-R-HANDLE	PT-R Handle complete Ningbo Ruyi chassis, standard version		1,0
D78	PTP-WH-ST-AS-180	PT wheel steering anti-static Ø180 mm		2,0

Nr.	Item code	Description	Special instructions	Quantity
D79	PTP-R-WH-TL-PU	PT-R loading wheel tandem polyurethane		1,0
D80	PTP-R-REP	PT-R Repair kit for pump		1,0
D81	FS-H+N+R-STST	Fork shoes HU + Noble + Ruyi stainless steel - bead blasted	Option: stainless steel fork shoes	1,0
D92	SAO-EP-LEVELSWITCH-EXI-C3041	Subassembly, Levelswitch EXi with C3041 chip	Option: legal for trade	1,0
D94	MP-MP-3	Mounting plate load cell 3 mm		12,0
D95	MP-RING-M12	Ring M12, din125A		4,0
D134	SA-HO-JUNC-EXI	Subassembly, Junction box for EX systems	Includes calibration board EB-4-LC-21-41	1,0
D153	SAO-PTP-R-BRAKE-FO	Subassembly, PT-R Footbrake, for painted Ningbo Ruyi chassis		1,0
D214	HO-HI-END-TH-STST-NO-PB	Top housing stainless steel, no pushbutton holes		1,0
D215	HOP-HI-END-TH-BOTTOM-STST	Bottom plate High End top housing stainless steel		1,0
D235	HOP-PACK-TH	Enclosure indicator housing		1,0
D236	MP-MP-STST	Mounting plate stainless steel (adaptor plate)		2,0
D237	PTP-J-LIMIT-PLATE-5MM	PT handle limitation for PT-J-STST(_PRO) chassis		1,0
D238	HOP-KEYHOLDER-EXI	Key holder housing EXi		1,0
D239	HO-EXI-XTRA-RAL3000	Housing 2100 EXi Xtra, RAL 3000		1,0
D240	HOP-HI-END-TH-FIXED-SUPPORT	Housing support High End top housing EXi, stainless steel		1,0