

## Using RESTful API to connect to RAVAS scales

RAVAS 3200 indicator with Wi-Fi module inside, using static IP addresses.

WMS sends RESTful commands to RIS application.  
RIS sends ASCII commands to the RAVAS indicators.

