

Indicator 5200 (cabled) 				
Nr.	Item code	Description	Special instructions	Quantity
D25	EB-CON-9/100V-12V-ISOLATED	Converter 9/100v 12v isolated		1.0
D51	CA-2-0,75-FLAT	Cable 2x0,75 flat - per meter		5.0
D56	EB-52-1AD-LC	AD board for load cell systems, i5200		1.0
D57	EP-FUSE-3,15A	Fuse 5x20 3,15A		1.0
D58	EP-FUSE-HOL-FL	Fuse holder floating		1.0
D59	HOP-RING-RUB-52-RAV-RAL3000	Red ring housing 52		1.0
D64	SA-MP-SUP-RAM-CLAMP-SQUARE	Subassembly, RAM-support clamp with square base		1.0
D65	SAO-IN-52-UPPER-M	Subass., indicator 52 in upper housing, incl. OIML AD board	Option: legal for trade	1.0
D65	SAO-IN-52-UPPER	Subassembly, indicator 52 in upper housing incl. AD board		1.0
D65	SAO-IN-52	Subassembly, Indicator 52 in upper housing		1.0
D66	SA-HOP-LOWER-52	Subassembly, Housing 52 lower part incl. grommet		1.0
D103	SA-IN-52-9/100-12V	Subassembly, indicator 5200, wired version, (ind. only)		1.0
D103	SA-IN-52-9/100-12V-M	Subassembly, indicator 5200, wired version, M, (ind. only)		1.0