

Indicator 6100 				
Nr.	Item code	Description	Special instructions	Quantity
D17	FR-61	Front panel indr 6100 (IT3000 red), inox housing		1,0
D18	IN-61	Indicator 6100 RAVAS		1,0
D220	EB-BOA-RELAY-12V	Board relay 12V		1,0
D251	EB-61-N-MAINBOARD	Mainboard indicator 6100 new		1,0
D252	INP-61-DISPLAY	Display indicator 6100		1,0
D253	INP-61-SIM-RS232	SIM indicator 6100 for extra RS232		1,0
D254	INP-61-MOD-I/O	Input-output module indicator 6100		1,0
D255	INP-61-MOD-CLOCK	Clock module indicator 6100		1,0