

Indicator 5200 (wireless)



Nr.	Item code	Description	Special instructions	Quantity
D25	EB-CON-9/100V-12V-ISOLATED	Converter 9/100v 12v isolated		1.0
D26	SA-IN-52-9/100-12V-REC	Subassembly, indicator 5200, wireless version, (ind. only)		1.0
D56	EB-52-REC	Receiver board, 5200		1.0
D57	EP-FUSE-3,15A	Fuse 5x20 3,15A		1.0
D58	EP-FUSE-HOL-FL	Fuse holder floating		1.0
D59	HOP-RING-RUB-52-RAV-RAL3000	Red ring housing 52		1.0
D64	SA-MP-SUP-RAM-CLAMP-SQUARE	Subassembly, RAM-support clamp with square base		1.0
D66	SA-HOP-LOWER-52	Subassembly, Housing 52 lower part incl. grommet		1.0